

AVA-1000

User's Manual

Fanless Scalable Railway Edge AI Platform



Manual Rev.:	Rev. 1.0
Revision Date:	June 19, 2025
Part Number:	50M-M41060-2000

Revision History

Revision	Description	Date
1.0	Initial release	2025-06-19

Preface

Copyright


Copyright 2025 ADLINK Technology, Inc. This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Disclaimer


The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer. In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Environmental Responsibility

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.



Battery Labels (for products with battery)



California Proposition 65 Warning



WARNING: This product can expose you to chemicals including acrylamide, arsenic, benzene, cadmium, Tris(1,3-dichloro-2-propyl)phosphate (TDCPP), 1,4-Dioxane, formaldehyde, lead, DEHP, styrene, DINP, BBP, PVC, and vinyl materials, which are known to the State of California to cause cancer, and acrylamide, benzene, cadmium, lead, mercury, phthalates, toluene, DEHP, DIDP, DnHP, DBP, BBP, PVC, and vinyl materials, which are known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Conventions

Take note of the following conventions used throughout this manual to make sure that users perform certain tasks and instructions properly.



NOTE:

Additional information, aids, and tips that help users perform tasks.



CAUTION:

Information to prevent **minor** physical injury, component damage, data loss, and/or program corruption when trying to complete a task.

ATTENTION: Informations destinées à prévenir les blessures corporelles mineures, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche.



WARNING:

Information to prevent **serious** physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.

AVERTISSEMENT: Informations destinées à prévenir les blessures corporelles graves, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche spécifique.

Table of Contents

Preface	iii
List of Figures.....	vi
List of Tables	vii
1 Introduction	9
1.1 Overview.....	9
1.2 Features.....	9
1.3 Packing List	10
1.4 Optional Accessories	10
2 Specifications	11
2.1 Product Specifications.....	11
2.2 Power Specifications.....	13
2.3 Functional Block Diagram	14
3 Mechanical Layout	15
3.1 Mechanical Dimensions	15
3.2 I/O Panel Connector Locations	16
4 Getting Started	21
4.1 Removing the Movable Cover	21
4.2 Installing the M.2 M-Key 2242 NVMe Storage Module	22
4.3 Installing M.2 2230 E-Key Wi-Fi/BT Modules	22
4.4 Installing M.2 B-Key 3042/52 5G Modules	24
4.5 Wall Mounting	27
4.6 Connecting a Ground Cable.....	27
4.7 Connecting the Power Supply	28
4.8 Starting the System.....	29
5 Connector Pinouts and Jumper Settings	31
5.1 External Connectors	31
5.2 Internal Connectors.....	35
5.3 Buttons and LEDs.....	38
6 System Interfaces.....	41
6.1 Installing Operating System	41
6.2 Install AVA-1000-iMX8MP_factory_yocto_2v1 ARM (Recovery image for SD Card to EMMC)	42
6.3 DIO Test	46
Safety Instructions	55
Getting Services	57

List of Figures

Figure 1: Functional block diagram.....	14
Figure 2: Mechanical dimensions	15
Figure 3: Front I/O panel connector locations	16
Figure 4: Front I/O panel connector locations with open lid	17
Figure 5: Front I/O panel connector locations	18
Figure 6: Side view without cover	19

List of Tables

Table 1: Front I/O panel connector descriptions (with open lid)	17
Table 2: Side I/O panel connector descriptions (without cover)	19

This page intentionally left blank.

1 Introduction

1.1 Overview

This user manual provides an overview on the AVA-1000. This user guide focuses on describing the special features of the AVA-1000 series variants (AVA-1000/x7433RE/8G/64G & AVA-1000/iMX8MP/8G/64G) and provides information on assembly, installation, operation, and maintenance on AVA-1000 to make the best use of the product. It is recommended to read the instructions in this user manual before using the product.

AVA-1000 is a compact fanless system targeting for Train-to-Ground, (T2G) communication, serving as an onboard gateway in the railway application. The CPU option includes Intel Amston Lake Atom series based on x86 architecture and NXP i.MX8M Plus based on ARM structure.

AVA-1000 is a fan-less communication gateway supporting on board GNSS, up to two 5G modem M.2-3042/3052 B-key slots and one M.2-2230 E-key slot for Wi-Fi and Bluetooth modules. Each modem slot supports 2 nano SIM cards. AVA-1000 is equipped by default with QMA antenna connectors for connectivity according to the configuration. The installation of the modems and modules can be completed by opening the lid after loosening the thumb screws on the panel.

For storage, the OS can be integrated into the eMMC on the SMARC module in AVA-1000. In addition, AVA-1000 provides an M.2-2230 M-key slot as another storage option.

1.2 Features

- EN 50155:2021 certified
- Fan-less and compact design
- Computing Processor:
 - Intel Atom x7433RE Quad-Core 1.5 GHz, 9W TDP, LPDDR5 8GB soldered
 - NXP i.MX8M Plus with Quad core ARM Cortex-A53, LPDDR4L 8GB soldered
 - Other CPU and DDR options upon request
- Front panel interfaces
 - 1x M12 K-coded male power connector with ignition
 - 3x 2.5G M12 X-coded female Ethernet ports
 - 1x 2x6 terminal block connector supporting RS-232/422/485, 4x DI/4x DO, and other optional interfaces.
 - Contact ADLINK for additional interfaces if needed
- Side panel interfaces for maintenance
 - 1x Reset button
 - 1x HDMI 1.4
 - 1x USB 3.1 Gen1 5G Type A
- Special ports for ARM based AVA-1000
 - 1x Micro SD for quickly flash image to eMMC
 - 1x Console port for system debug
 - 1x Micro-B support OTG mode and NXP serial download mode
 - 1x Dip switch for boot mode selection
- Open lid for internal modules installation and removal
 - 2x M.2-3042/4052 B Key slots for 5G/LTE modem installation
 - 1x M.2-2230 E Key slot for Wi-Fi/BT or other expansion
 - 1x M.2-2242 M Key slot for NVME storage
 - 1x onboard u-blox Neo-M9N GNSS module
- Rear side antenna
 - 11pcs QMA connectors for x86 based and 7pcs for ARM based

1.3 Packing List

Please check that your package contains the items listed below. If you discover any damaged or missing items, please contact your ADLINK representative for assistance.

- AVA-1000 hardware configured as ordered
- AVA-1000 mating power cable with terminal block (PN: 30-22184-0000-A0)
- AVA-1000 wall mount kit
- Terminal block for DI/DO and COM (PN: 20-C2041-2060)
- AVA-1000 Wi-Fi AX210 Thermal Part (PN: 58-10643-200E)
- AVA-1000 FN990 Bottom PAD Thermal Part (PN: 58-10643-300E)
- Technical service card

For modem and modules not supported in the list, please notify ADLINK representatives for thermal solution.



DO NOT install or apply power to equipment that is damaged or if there is missing/incomplete equipment. Retain the shipping carton and packing materials for inspection. Please contact your ADLINK dealer/vendor immediately for assistance. Obtain authorization from your dealer before returning any product to ADLINK.

1.4 Optional Accessories

The AVA-1000 is shipped without add-on modules. The approved modules is listed as below:

- AVA-1000 24VDC IN AC-DC PSU (PN: 91-95376-000E)
- 5G modem FN990A40-HP (PN: 29-D0990-E000)
- Intel AX210 Wi-Fi module (PN: 29-E0210-2010)
- ADLINK NVME series. Please contact ADLINK representative for selection

2 Specifications

2.1 Product Specifications

Products	AVA-1000/x7433RE/8G/64G	AVA-1000/iMX8MP/8G/64G
System	Intel Atom x7433RE Quad-Core 1.5 GHz, 9W TDP	NXP i.MX8M Plus with Quad core ARM Cortex-A53
	LPDDR5 8 Gbyte soldered by default	LPDDR4L-4266 8GB soldered by default
	AMI® Aptio V	-
	3x 2.5GbE via M12 X-coded	3x 2.5GbE via M12 X-coded
	4x DI/4 DO in 1x 2x6 terminal block	4x DI/4 DO in 1x 2x6 terminal block
	1x RS-232/422/485 in 1x 2x6 terminal block	1x RS-232/422/485 in 1x 2x6 terminal block
	1x HDMI 1.4 1920*1080 @ 60Hz	1x HDMI 1.4 1920*1080 @ 60Hz
	1x USB 3.1 Gen1 5G Type A	1x USB 3.1 Gen1 5G Type A
	I2C, CAN reserved upon request	I2C, CAN reserved upon request
	-	1x Console port for system debug 1x Micro-B support OTG mode and NXP serial download mode 1x Dip switch for boot mode selection Covered with lids for security purpose
Storage	64GB eMMC by default	64GB eMMC by default
	-	1x Micro SD slot for image loading Covered with lids for security purpose
	1 M.2-2242 M Key with PCIe Gen3 for PCIe/NVME only	1 M.2-2242 M Key with PCIe Gen2 for PCIe/NVME only
Connectivity	2x M.2-3042/4052 B Key (USB 3.0+USB 2.0) for 5G/LTE	1x M.2-3042/4052 B Key (USB 3.0+USB 2.0) for 5G/LTE
	1x M.2-2230 E Key (PCIe Gen3/ USB 2) for WiFi and BT	1x M.2-2230 E Key (PCIe Gen2/ USB 2) for Wi-Fi and BT
	GNSS receiver supporting GPS, Galileo, GLONASS, BeiDou (NEO-M9N-0-12)	GNSS receiver supporting GPS, Galileo, GLONASS, BeiDou (NEO-M9N-0-12)
	8x antenna QMA connectors for 5G/LTE	4x antenna QMA connectors for 5G/LTE
	2x antenna QMA connectors for Wi-Fi	2x antenna QMA connectors for Wifi
	1x antenna QMA connectors for GNSS	1x antenna QMA connectors for GNSS
	4x Nano Sim Card on RF board 2 Sim per one 5G modem	2x Nano Sim Card on RF board for ARM version 2 Sim per one 5G modem

Miscellaneous	1x Power/Reset LED (Green) 1x Watchdog LED (Yellow) 3x Ethernet Link LEDs (Green) 12x User define LEDs (Green)	1x Power/Reset LED (Green) 1x Watchdog LED (Yellow) 3x Ethernet Link LEDs (Green) 12x User define LEDs (Green)
	1x Reset button	1x Reset button
	TPM 2.0	TPM 2.0
Power interface	M12 A-coded support 24V to 110V DC nominal (EN50155), 10ms hold-up time (acc. EN50155, class S2, C1) Ignition support	M12 A-coded support 24V to 110V DC nominal (EN50155), 10ms hold-up time (acc. EN50155, class S2, C1) Ignition support
Mechanical	Aluminum heatsink	Aluminum heatsink
	Passive cooling Fan-less design Suggested air flow 0.6m/s	Passive cooling Fan-less design Suggested air flow 0.6m/s
	Stainless steel M6 20mm stud	Stainless steel M6 20mm stud
	Wall mount	Wall mount
	EN60529 IP40	EN60529 IP40
	L: 220mm; W:130mm; H: 72.3mm	L: 220mm; W:130mm; H: 72.3mm
	2.070 kg with 2x modems, 1x Wi-Fi, 1x NVME modules	2 kg with 1x modem, 1x Wi-Fi, 1x NVME modules
MTBF	220,051 hrs. by Telcordia Issue 4, 40 degree C, GB, GC	250,350 hrs. by Telcordia Issue 4, 40 degree C, GB, GC
Conformal Coating	Coating PCBA	Coating PCBA
Battery	MuRata CR2032X Battery by default	MuRata CR2032X Battery by default
Software	AMI® Aptio V UEFI BIOS	-
	Ubuntu Linux 22.04	Yocto Linux
	1 to 255 sec. system reset	1 to 255 sec. system reset
Operating Temperature	Depending on SMARC module selection -40 °C to +70 °C, +85°C for 10 min (-40 °F to 158 °F, 185 °F for 10 min) according to EN50155, class OT4, ST1	Depending on SMARC module selection -40 °C to +70 °C, +85°C for 10 min (-40 °F to 158 °F, 185 °F for 10 min) according to EN50155, class OT4, ST1
Storage Temperature	-40°C to +85°C	-40°C to +85°C
Humidity	+25°C to +55 °C, 95 % (acc. EN50155)	+25°C to +55 °C, 95 % (acc. EN50155)
EMC	EN 50155:2021 Clause 13.4.9 EN 50121-3-2	EN 50155:2021 Clause 13.4.9 EN 50121-3-2
Safety	EN 50155:2021	EN 50155:2021
	EN45545-2:2013+A1:2015 (HL 1-3) EL9 for PCB (R24 / R25) Exclude add on modules	EN45545-2:2013+A1:2015 (HL 1-3) EL9 for PCB (R24 / R25) Exclude add on modules

2.2 Power Specifications

2.2.1 AVA-1000 Power Consumption

Ubuntu 22.04.4 LTS X86:

	AVA-1000 A2 version
CPU	Intel(R) Atom(TM) x7433REx4
Memory	8GB
OS	Ubuntu 22.04.4 LTS
Idle mode	
24V(A) Adapter	0.68
Power consumption(W)	16.32
MAX mode	
24V(A) Adapter	1.45
Power consumption(W)	34.8

AVA-1000-iMX8MP_yocto_2v1 ARM:

	AVA-1000 A2 version
CPU	ARM Cortex-A53 P-duke
Memory	8GB
OS	
Idle mode	
24V(A) Adapter	0.58
Power consumption(W)	13.92
MAX mode	
24V(A) Adapter	1.32
Power consumption(W)	31.68


3 Mechanical Layout

3.1 Mechanical Dimensions



All dimensions are in millimeters, unless noted.

NOTE:



3.2 I/O Panel Connector Locations

3.2.1 Front View



Figure 3: Front I/O panel connector locations




Figure 4: Front I/O panel connector locations with open lid

Table 1: Front I/O panel connector descriptions (with open lid)

No.	Function	Approved module	Remark
1	M.2-2030 E key for Wi-Fi /BT	Intel AX-210, Wi-Fi/BT M.2 Card	Need a compatible thermal kit for assembly. Assemble procedure is in the following chapter.
2	M.2-3042/3052 B key for 5G/LTE modem	Telit FN990A28 Telit FN990A40	Need a compatible thermal kit for assembly. Assemble procedure is in the following chapter.
3	M.2-3042/3052 B key for 5G/LTE modem	Telit FN990A28 Telit FN990A40	Need a compatible thermal kit for assembly. Assemble procedure is following chapter. Available on AVA-1000, based on x86 platform and ARM platform
4	1 st Nano SIM slot for modem No. 1		
5	2 nd Nano SIM slot for modem No. 1		
6	1 st Nano SIM slot for modem No. 2		
7	2 nd Nano SIM slot for modem No. 2		
8	M.2-2242 M key for NVME		Need a compatible thermal pad for heat dissipation

3.2.2 Side View



The IO interface is only for maintenance purposes.

Figure 5: Front I/O panel connector locations




Figure 6: Side view without cover

Table 2: Side I/O panel connector descriptions (without cover)

No.	Function	Function
1	Dip switch for boot mode selection	To selection boot mode
2	Micro-B	Support OTG mode and NXP serial download mode
3	Console	For system debug
4	Micro SD	For flash image to EMMC
5	USB3.0 GEN2 TypeA	Maintenance
6	HDMI	Maintenance
7	Reset	Reset system

This page intentionally left blank.

4 Getting Started

Follow the instructions describing the installation of SIM cards, Wi-Fi, cellular and M.2 NVMe modules; ground cable; and DC power supply.




NOTE:

MXM and CAN bus modules must be installed at the factory. Please contact your local ADLINK representative for more information.

4.1 Removing the Movable Cover


To install the optional modules, first remove the movable cover as illustrated below:

1. Place the box PC on a suitable surface with the top side facing up. Remove the 2 thumb screws from the top-right side as indicated below.
2. Lift the rear cover off of the box PC chassis.



4.2 Installing the M.2 M-Key 2242 NVMe Storage Module


To install the M.2 M-Key 2242 NVMe module, insert the module into the slot and attach the thermal pad, securing it with M2.5 screws, as shown below.



M.2 modules require an additional thermal solution when operated above 60°C. Please contact your local ADLINK representative for more information.


Secure the NVME module: Insert the NVME module into the corresponding slot and fasten it with screws.

4.3 Installing M.2 2230 E-Key Wi-Fi/BT Modules



The GNSS QMA antenna is preassembled during the production stage.


The Aux1 and Aux 2 are assigned for Wi-Fi modules. The Wi-Fi module should be placed at the location marked as below.



1. To install the Wi-Fi/BT module, Find the heat spreader and placed on the location for Wifi M.2. Place the thermal pad at the location marked as below.





2. Attach the AUX1 and AUX2 QMA to I-PEX4 connector to the Wi-Fi module and fasten the screw. Organize the cable prevent it from being overlap on the thermal solution. Cover the heat spreader and fasten two screws.



4.4 Installing M.2 B-Key 3042/52 5G Modules


There are two M.2 B Key 3042/3052 5G module slots. Slot 1 is supported for both x86 and ARM version. Slot 2 is supported only for AVA-1000 based on x86 architecture. Slot 1 a is connected to AUX7, AUX8, AUX9, AUX10. Slot 2 is connected to AUX3, AUX4, AUX5, AUX6.






The 5G modem assembly is the same for both slot 1 and slot 2.

1. Step 1: Find the thermal pad for 5G modem FN990 and place it at the PCB with gold plate.




2. Step 2: Attach the QMA to IPEX1 cables at the location assigned on the modem according to the silkscreen on the PCBA of the modem.



3. Attach the IPEX bracket onto the modem. The bracket is to prevent the IPEX connector from falling off. Sliding from the end of the modem is recommended. Pay attention to the cable from interfere the bracket.




4. Fasten the 5G modem screws. Organize the cable to the edge of the chassis. It is to prevent the cables from overlapping on the thermal pad.



Step 5: Close the cover. The thermal pad on the cover will help dissipate the heat to the housing.

4.5 Wall Mounting

The AVA-1000 can be wall or surface mounted using the wall mount brackets and screws provided. If wall mounting, make sure the wall can support the weight of the device. Secure the brackets to the chassis using the 4 screws provided.




4.6 Connecting a Ground Cable



CAUTION:

Connect the ground cable before making any other connections. When disassembling the system, always detach the ground cable last.

- Use a ground cable with a cross section of at least 0.823mm² (18AWG) and an M5 size ring terminal.
- Slide the ring terminal onto the ground stud and secure it with the locking M5 nut.



4.7 Connecting the Power Supply




Connect the ground cable before making any other connections. When disassembling the system, always detach the ground cable last.



- Work on the computer system may only be carried out by personnel qualified for the specific task and who have the training and experience to identify risks and avoid potential hazards.
- Make sure that a ground cable has been connected to the system before connecting an external power supply and switching on the system.
- Make sure that the voltage supplied by the external power supply conforms to specifications of the system.

Connect the power supply to the 5-pin M12 K-coded connector on the front of the chassis. The device will power up when the power supply is turned on.



The user must provide the +24 to 110VDC

4.8 Starting the System

Upon starting up, the system will auto-detect storage devices and boot from the operating system, if found. To change the boot device order, press or <Esc> to enter BIOS setup menu and change the Boot Option settings. If no operating system is found, the system will enter the BIOS setup menu automatically.

The AVA-1000 is delivered without an operating system installed.

This page intentionally left blank.


5 Connector Pinouts and Jumper Settings

5.1 External Connectors

Please refer to 3.2.1 Mechanical Layout Front View for connector locations.


5.1.1 M12 A-Coded Connectors

Pin #	Signal Name
1	IGN
2	DC+
3	DC+
4	DC+
5	DC+




5.1.2 LAN Connector

Pin #	Signal Name
1	MDI_T_P0
2	MDI_T_N0
3	MDI_T_P1
4	MDI_T_N1
5	MDI_T_P3
6	MDI_T_N3
7	MDI_T_N2
8	MDI_T_P2




5.1.3 USB 3.0 Connector

Pin #	Signal Name
1	USB3.0_P5VA
2	USB2_CMAN
3	USB2_CMAP
4	GND
5	USB3A_CMRXN
6	USB3A_CMRXP
7	GND
8	USB3A_CMTXN
9	USB3A_CMTXP




5.1.4 HDMI Connector

Pin #	Signal Name	Pin #	Signal Name
1	TMDS Data2+	2	TMDS Data2 Shield
3	TMDS Data2-	4	TMDS Data2-
5	TMDS Data1 Shield	6	TMDS Data1-
7	TMDS Data2-	8	TMDS Data0 Shield
9	TMDS Data0-	10	TMDS Data2-
11	TMDS Clock Shield	12	TMDS Clock-
13	CEC	14	SDA
15	SCL	16	SDA
17	DDC/CEC Ground	18	+5 V Power
19	Hot Plug Detect		




5.1.5 GPIO and COM Connectors

SMARC module: LEC-ASL	SMARC connector pin	Carrier board	AVA-1000 GPIO connector pin	Remark
O2_GPIO_7	P115	S_GPIO07_3V_CN	2	DO
O2_GPIO_6_TACHIN (O2_GPIO_6)	P114	S_GPIO06_3V_CN	3	DO
O2_GPIO_11	P119	S_GPIO11_3V_CN	5	DI
O2_GPIO_10	P118	S_GPIO10_3V_CN	6	DI




5.1.6 uUSB Connectors

Pin #	Signal Name
1	SDIO_R_D2
2	SDIO_R_D3
3	SDIO_R_CMD
4	P_+SD
5	SDIO_R_CK
6	GND
7	SDIO_R_D0
8	SDIO_R_D1
9	GND
10	GND
11	SDIO_R_CD#
12	GND




5.1.6.1 uUSB Connectors (For OTG)

Pin #	Signal Name
1	P_+5V_UUSB_FLASH
2	USB0_DN_CN
3	USB0_DP_CN
4	USB0_OTG_ID_CN
5	GND




5.1.6.2 uUSB Connectors (For Console)

Pin #	Signal Name
1	P_+5V_MUSB
2	USB_UART_HS_DB_N_CN
3	USB_UART_HS_DB_P_CN
4	Test point
5	GND




5.1.7 Reset Connectors

Pin #	Signal Name
T1	GND
T2	RESET_IN#_5V
T3	GND
T4	GND



5.1.8 Switch Connectors


Pin #	Signal Name
1	GND
2	GND
3	FORCE_RECOV#
4	BOOT_SEL_SW



Pin	1	2	Boot Source	Remark
Status	ON	OFF	From uSD card	Only 8MP(ARM)
	ON	ON	From SMARC model EMMC	

5.2 Internal Connectors


5.2.1 M.2 M-Key 2242 PCIe module Connector



Pin #	Signal Name	Pin #	Signal Name	Pin #	Signal Name
1	M.2M_CONFIG_3	31	NC	69	M.2M_CONFIG_1
2	P_+3V3_M.2M	32	NC	70	P_+3V3_M.2M
3	GND	33	GND	71	GND
4	P_+3V3_M.2M	34	NC	72	P_+3V3_M.2M
5	NC	35	NC	73	GND
6	NC	36	NC	74	P_+3V3_M.2M
7	NC	37	NC	75	M.2M_CONFIG_2
8	NC	38	PU 10K to 3.3V		
9	GND	39	GND		
10	Test point	40	NC		
11	NC	41	PCIE_B_RX_N_R		
12	P_+3V3_M.2M	42	NC		
13	NC	43	PCIE_B_RX_P_R		
14	P_+3V3_M.2M	44	NC		
15	GND	45	GND		
16	P_+3V3_M.2M	46	NC		
17	NC	47	PCIE_B_TX_N_C		
18	P_+3V3_M.2M	48	NC		
19	NC	49	PCIE_B_TX_P_C		
20	NC	50	PCIE_B_RST_N_3V_CN		
21	M.2M_CONFIG_0	51	GND		
22	NC	52	M2_KEY-M_CLK_REQ_N		
23	NC	53	PCIE_B_REFCLK_N_R		
24	NC	54	M2_KEY-M_PEWAKE_N		
25	NC	55	PCIE_B_REFCLK_P_R		
26	NC	56	NC		
27	GND	57	GND		
28	NC	58	NC		
29	NC	67	NC		
30	NC	68	M.2_M_SUSCLK		

5.2.2 M.2 B-Key 3042 5G Module Connector

Pin	Signal Name	Pin	Signal Name
1	NC	2	3.3V
3	GND	4	3.3V
5	GND	6	FULL CARD OFF-L
7	USB2 DP	8	W DIS-L
9	USB2 DM	10	LED-L
11	GND		
KEY-B			
21	NC	20	NC
23	NC	22	NC
25	NC	24	NC
27	GND	26	NC
29	USB3 RX N	28	NC
31	USB3 RX P	30	SIM RST1
33	GND	32	SIM CLK1
35	USB3 TX N	34	SIM DAT1
37	USB3 TX P	36	SIM PWR1
39	GND	38	NC
41	PCIE RX N	40	SIM DET2
43	PCIE RX P	42	SIM DAT2
45	GND	44	SIM CLK2
47	PCIE TX N	46	SIM RST2
49	PCIE TX P	48	SIM PWR2
51	GND	50	PERST-L
53	PCIE CLK N	52	CLKREQ-L
55	PCIE CLK P	54	NC
57	GND	56	NC
59	NC	58	NC
61	NC	60	NC
63	NC	62	NC
65	NC	64	NC
67	NC	66	SIM DET1
69	NC	68	NC
71	GND	70	3.3V
73	GND	72	3.3V
75	NC	74	3.3V




5.2.3 M.2 E-Key 2230 Wi-Fi Module Connector

Pin	Signal Name	Pin	Signal Name
1	GND	2	3.3V
3	USB2_DP	4	3.3V
5	USB2_DM	6	WIFI_LED1
7	GND	8	NC
9	NC	10	NC
11	NC	12	NC
13	NC	14	NC
15	NC	16	WIFI_LED2
17	NC	18	WIFI_VIO_CFG
19	NC	20	NC
21	NC	22	NC
23	N/C	24	N/C
Key E			
33	GND	32	NC
35	PCIE_TX_DP	34	NC
37	PCIE_TX_DN	36	NC
39	GND	38	NC
41	PCIE_RX_DP	40	NC
43	PCIE_RX_DN	42	NC
45	GND	44	NC
47	PCIE_CLK_DP	46	NC
49	PCIE_CLK_DN	48	NC
51	GND	50	NC
53	PCIE_CLKREQ-L	52	PCIE_RST-L
55	PEWAKE0-L	54	WIFI_BT_DIS-L
57	GND	56	WIFI_DIS-L
59	NC	58	NC
61	NC	60	NC
63	GND	62	NC
65	NC	64	NC
67	NC	66	NC
69	GND	68	NC
71	NC	70	NC
73	NC	72	3.3V
75	GND	74	3.3V

5.3 Buttons and LEDs

5.3.1 Power Button

The power button is non-latching, the system turns on when the button is pressed, then the power LED illuminates. If the system hangs, pressing the button will completely shut it down.



System status	Power LED (GREEN)
Power On	On
Power Off	Off

5.3.2 Reset Button

The reset button is non-latching. The system is restarts when the button is pressed. If the system hangs, press the button to restart it.

5.3.3 Status LEDs



LED indicator	Color	Description
Power	Green	1 x power on and reset LED (Green), LED on when power on. LED off when power off.
Watchdog	Yellow	1 x WDT LED (Yellow) , Indicates watchdog timer status. When the watchdog timer starts, the LED flashes. When the timer is expired, the system will auto reboot.
Lan	Green	1 x 1G Ethernet (signal from USB) (Green) 2 x 1G Ethernet (signal from SMARC) (Green)
Wi-Fi	Green	4 x Wi-Fi LED (Green)
Customer indicator LEDs	Green	8 x customer indicator LEDs (2x 4 Green)


This page intentionally left blank.

6 System Interfaces

6.1 Installing Operating System


6.1.1 Install Ubuntu 22.04.4 LTS (Kernel Linux adlink-ava-1v3 6.5.0-25-generic) X86

Use Rufus tool recovery **AVA-1000_Ubuntu_22.04.4_x64_IMG_1v3.iso** image





6.2 Install AVA-1000-iMX8MP_factory_yocto_2v1 ARM (Recovery image for SD Card to EMMC)


1. Download the **AVA-1000-iMX8MP_factory_yocto_2v1** image and unzip it with 7-zip.
2. Please use Rufus tool to recover the **AVA-1000-iMX8MP_factory_yocto_2v1** image to an SD Card (SD card must be more than 16G).




3. Set **jump Switch SW1 to ON / SW2 to OFF** for SD card image recovery to EMMC, and plug in the SD card slot.



4. Use a Micro USB to USB Type-A cable to connect the Console slot to the Host PC (Window 10).



5. Check the COM port in Windows Device Manager. Open PuTTY, Select connection type:Serial, and set COM port and speed (115200).



6. Once the AVA-1000 is powered ON, PuTTY will show the SD card image being restored to eMMC.

```
COM3 - PuTTY
[*** ] (1 of 2) A start job is running for...cal Compatibility (33s / no limit)
[ 39.453047] usb 2-1.3: new SuperSpeed USB device number 5 using xhci-hcd
[ 39.482072] usb 2-1.3: LPM exit latency is zeroed, disabling LPM.
[ 39.679100] option 2-1.3:1.0: GSM modem (1-port) converter detected
[ 39.686022] usb 2-1.3: GSM modem (1-port) converter now attached to ttyUSB0
[ 39.728584] qmi_wwan 2-1.3:1.2: cdc-wdm0: USB WDM device
[ 39.735003] qmi_wwan 2-1.3:1.2 wwan0: register 'qmi_wwan' at usb-xhci-hcd.1.a
uto-1.3, WWAN/QMI device, 7e:9d:c8:d3:52:01
[ 39.746480] option 2-1.3:1.3: GSM modem (1-port) converter detected
[ 39.753116] usb 2-1.3: GSM modem (1-port) converter now attached to ttyUSB1
[ 39.760482] option 2-1.3:1.4: GSM modem (1-port) converter detected
[ 39.767156] usb 2-1.3: GSM modem (1-port) converter now attached to ttyUSB2
[ 39.774564] option 2-1.3:1.5: GSM modem (1-port) converter detected
[ 39.781593] usb 2-1.3: GSM modem (1-port) converter now attached to ttyUSB3
[ 39.789061] option 2-1.3:1.6: GSM modem (1-port) converter detected
[ ** ] (1 of 2) A start job is running for...cal Compatibility (38s / no limit)
[ 43.680987] kauditd_printk_skb: 6 callbacks suppressed
[ 43.680997] audit: type=1334 audit(1677837294.336:16): prog-id=14 op=UNLOAD
[*** ] (2 of 2) A start job is running for...local if it exist (55s / no limit)
[ 60.410432] imx-sdma 30e10000.dma-controller: firmware found.
[ 60.416243] imx-sdma 30bd0000.dma-controller: firmware found.
[ ** ] (2 of 2) A start job is running for...local if it exist (59s / no limit)
[*** ] (1 of 2) A start job is running for...Compatibility (1min 2s / no limit)
```

SD card image successfully restored to eMMC.



```
COM3 - PuTTY
[ 134.821987] EXT4-fs (mmcblk2p3): mounted filesystem with ordered data mode. Q
[ * ] (2 of 2) A start job is running for... if it exist (2min 11s / no limit)
[ 136.446166] EXT4-fs (mmcblk2p3): unmounting filesystem.
[ 136.522999] EXT4-fs (mmcblk2p5): mounted filesystem with ordered data mode. Q
[ * ] (2 of 2) A start job is running for... if it exist (2min 35s / no limit)
[ 160.678568] EXT4-fs (mmcblk2p2): mounted filesystem with ordered data mode. Q
[** ] (2 of 2) A start job is running for... if it exist (2min 46s / no limit)
[ OK ] Started /etc/rc.local Compatibility.
[ OK ] Started Getty on tty1.
[ OK ] Started Serial Getty on ttymxcl.
[ OK ] Reached target Login Prompts.

NXP i.MX Release Distro 6.1-mickledore AVA-1000 ttymxcl

AVA-1000 login: [ 189.248774] EXT4-fs (mmcblk2p5): unmounting filesystem.
[ 189.362704] EXT4-fs (mmcblk2p2): mounted filesystem with ordered data mode. Q
uota mode: none.
[ 191.453132] iwlwifi 0000:03:00.0: Direct firmware load for iwlwifi-ty-a0-gf-a
0-69.ucode failed with error -2
[ 191.463018] iwlwifi 0000:03:00.0: Falling back to sysfs fallback for: iwlwifi
-ty-a0-gf-a0-69.ucode
[ 199.140742] EXT4-fs (mmcblk2p2): unmounting filesystem.
[ 199.164726] mmcblk2: p1 p2 p3 p4 < p5 p6 p7 >

AVA-1000 login: █
```

7. Set jump **Set SW1 to OFF / SW2 to OFF**. Remove the SD card and Micro USB cable, then connect the HDMI cable and boot from eMMC.



6.3 DIO Test


6.3.1 Ubuntu 22.04.4 LTS (Kernel Linux adlink-ava-1v3 6.5.0-25-generic) X86 GPIO Test

- Platform: AVA-1000
- OS: Ubuntu 22.04.4 LTS (Kernel Linux adlink-ava-1v3 6.5.0-25-generic)

The gpio chip have GPIOs include 12 pins, use the GPIO loopback test fixture test



Identify the GPIO number for the DIO pin



Check GPIO function number in the platform schematic


Refer the platform schematic, there are 2 * DI(O2_GPIO_11/ O2_GPIO_10) and 2 * DO(O2_GPIO_7/ O2_GPIO_6).


SMARC module: LEC-ASL	SMARC connector pin	Carrier board	AVA-1000 GPIO connector pin	Remark
O2_GPIO_7	P115	S_GPIO07_3V_CN	2	DO
O2_GPIO_6_TACHIN (O2_GPIO_6)	P114	S_GPIO06_3V_CN	3	DO
O2_GPIO_11	P119	S_GPIO11_3V_CN	5	DI
O2_GPIO_10	P118	S_GPIO10_3V_CN	6	DI

(1) GPIO connector



(2) Carrier board: Level shift for GPIO






(3) SMARC module: LEC-ASL

GPIO expander on the SMARC module (LEC-ASL).

I2C GPIO Expander



6.3.2 Test GPIO function

Digital Input & Output

DIO function

AVA-1000 platform has 4 DI & 4 DO from SMARC HW pin GPIOs.

Digital Input & Output Table

Digital Input	HW Pin	Digital Output	HW Pin
DI1	GPIO6	DO1	GPIO10
DI2	GPIO7	DO2	GPIO11
DI3	GPIO8	DO3	GPIO12
DI4	GPIO9	DO4	GPIO13

DIO control

Using SEMA to control SMARC HW pin.

Config DIO HW pin & set value default low

```
$ sudo semautl /i2c write_raw 2 0x3f 2 0e 3c # 0011 1100
$ sudo semautl /i2c write_raw 2 0x3f 2 0f 31 # 0011 0001
$ sudo semautl /i2c write_raw 2 0x3f 2 10 00 # 0000 0000
$ sudo semautl /i2c write_raw 2 0x3f 2 11 0e # 0000 1110
```

Control DO output level

DO1 high

```
$ sudo semautl /i2c write_raw 2 0x3f 2 11 7f
```

DO2 high

```
$ sudo semautl /i2c write_raw 2 0x3f 2 11 bf
```

DO3 high

```
$ sudo semautl /i2c write_raw 2 0x3f 2 10 01
```

DO4 high

```
$ sudo semautl /i2c write_raw 2 0x3f 2 10 02
```

DOx low

```
$ sudo semautl /i2c write_raw 2 0x3f 2 10 00
```

```
$ sudo semautl /i2c write_raw 2 0x3f 2 11 3f
```

Using SEMA to control SMARC HW pin.

Get DI input level

```
$ sudo semautl /i2c read_raw 2 0x3f 10 1
```

read DI hex value

Return value 00 is a hexadecimal value. (0000 0000)

If DI1 is high, the hex value is 04 (0000 0100)

If DI2 is high, the hex value is 08 (0000 1000)

If DI3 is high, the hex value is 10 (0001 0000)

If DI4 is high, the hex value is 20 (0010 0000)

```
root@adlink-ava-1000-1v3: /home/adlink/AVA-1000/smea/sema-linux
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 0e 3c
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 0f 31
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 10 00
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 11 3f
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 11 7f
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c read_raw 2 0x3f 10 1
Read data:
00 : 04
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 11 bf
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c read_raw 2 0x3f 10 1
Read data:
00 : 08
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c write_raw 2 0x3f 2 11 ff
Data Written Successfully
root@adlink-ava-1000-1v3:/home/adlink/AVA-1000/smea/sema-linux# sudo semautl /i2c read_raw 2 0x3f 10 1
Read data:
00 : 0c
```

6.3.3 Test LED function

LED

LEC control

Using SEMA to control LED HW pin

```
# Config LED HW pin & set LED default off
$ semautl /i2c write_raw 2 0x71 2 0e 00
$ semautl /i2c write_raw 2 0x71 2 0f 00
$ semautl /i2c write_raw 2 0x71 2 10 f0
$ semautl /i2c write_raw 2 0x71 2 11 00
```

Control LED

```
# set LED all on
$ sudo semautl /i2c write_raw 2 0x71 2 10 ff
$ sudo semautl /i2c write_raw 2 0x71 2 11 ff

# set LED column1 on
$ sudo semautl /i2c write_raw 2 0x71 2 10 ff
$ sudo semautl /i2c write_raw 2 0x71 2 11 00

# set LED column2 off
$ sudo semautl /i2c write_raw 2 0x71 2 10 f0
$ sudo semautl /i2c write_raw 2 0x71 2 11 0f

# set LED column3 on
$ sudo semautl /i2c write_raw 2 0x71 2 10 f0
$ sudo semautl /i2c write_raw 2 0x71 2 11 f0

# set LED all off
$ sudo semautl /i2c write_raw 2 0x71 2 10 f0
$ sudo semautl /i2c write_raw 2 0x71 2 11 00
```

6.3.4 AVA-1000-iMX8MP_factory_yocto_2v1 ARM GPIO Test

6.3.4.1 Test GPIO function

AVA-1000 ARM System, DIO Port plug-in DIO test fixture



Digital Input & Output

connect:

GPIO6<->GPIO10

GPIO7<->GPIO11

GPIO8<->GPIO12

GPIO9<->GPIO13

#cd /sys/class/gpio_switch/

#echo 1 > D001


#echo 1 > D002

#cat DI01

1

#cat DI02


1



6.3.5 Test LED function


LED1~LED12 ON

```
#cd /sys/class/ leds /
# echo 1 > /sys/class/leds/usr_led01/brightness
# echo 1 > /sys/class/leds/usr_led02/brightness
# echo 1 > /sys/class/leds/usr_led03/brightness
# echo 1 > /sys/class/leds/usr_led04/brightness
# echo 1 > /sys/class/leds/usr_led05/brightness
# echo 1 > /sys/class/leds/usr_led06/brightness
# echo 1 > /sys/class/leds/usr_led07/brightness
# echo 1 > /sys/class/leds/usr_led08/brightness
# echo 1 > /sys/class/leds/usr_led9/brightness
# echo 1 > /sys/class/leds/usr_led10/brightness
# echo 1 > /sys/class/leds/usr_led11/brightness
# echo 1 > /sys/class/leds/usr_led12/brightness
```



LED1~LED12 OFF

```
#cd /sys/class/ leds /
# echo 0 > /sys/class/leds/usr_led01/brightness
# echo 0 > /sys/class/leds/usr_led02/brightness
# echo 0 > /sys/class/leds/usr_led03/brightness
# echo 0 > /sys/class/leds/usr_led04/brightness
# echo 0 > /sys/class/leds/usr_led05/brightness
# echo 0 > /sys/class/leds/usr_led06/brightness
# echo 0 > /sys/class/leds/usr_led07/brightness
# echo 0 > /sys/class/leds/usr_led08/brightness
# echo 0 > /sys/class/leds/usr_led9/brightness
# echo 0 > /sys/class/leds/usr_led10/brightness
# echo 0 > /sys/class/leds/usr_led11/brightness
# echo 0 > /sys/class/leds/usr_led12/brightness
```



Safety Instructions

For user safety, please read and follow all instructions, Warnings, Cautions, and Notes marked in this manual and on the associated device before handling/operating the device, to avoid injury or damage.

S'il vous plaît prêter attention stricte à tous les avertissements et mises en garde figurant sur l'appareil, pour éviter des blessures ou des dommages.

- ▶ Read these safety instructions carefully.
- ▶ Keep the User's Manual for future reference.
- ▶ Read the Specifications section of this manual for detailed information on the recommended operating environment.
- ▶ When installing/mounting or uninstalling/removing device; or when removal of a chassis cover is required for user servicing ([See "Getting Started"](#)):
 - [> Turn off power and unplug any power cords/cables.
 - [> Reinstall all chassis covers before restoring power.
- ▶ To avoid electrical shock and/or damage to device:
 - [> Keep device away from water or liquid sources.
 - [> Keep device away from high heat or humidity.
 - [> Keep device properly ventilated (do not block or cover ventilation openings).
 - [> Always use recommended voltage and power source settings.
 - [> Always install and operate device near an easily accessible electrical outlet.
 - [> Secure the power cord (do not place any object on/over the power cord) and connect it to a socket-outlet with earthing connection.
 - [> Only install/attach and operate device on stable surfaces and/or recommended mountings.
- ▶ If the device will not be used for long periods of time, turn off and unplug from its power source.
- ▶ Never attempt to repair the device, which should only be serviced by qualified technical personnel using suitable tools.
- ▶ A Lithium-type battery may be provided for uninterrupted backup or emergency power.




CAUTION:

Risk of explosion if battery is replaced with one of an incorrect type; please dispose of used batteries appropriately.

Risque d'explosion si la pile est remplacée par une autre de type incorrect. Veuillez jeter les piles usagées de façon appropriée.

- ▶ The device must be serviced by authorized technicians when:
 - [> The power cord or plug is damaged.
 - [> Liquid has entered the device interior.
 - [> The device has been exposed to high humidity and/or moisture.
 - [> The device is not functioning or does not function according to the User's Manual.
 - [> The device has been dropped and/or damaged and/or shows obvious signs of breakage.
- ▶ Disconnect the power supply cord before loosening the thumbscrews and always fasten the thumbscrews with a screwdriver before starting the system up.
 - [> The equipment is not intended to be installed or used in a home, school, or public area accessible to the general population.
 - [> The knurled thumb screws with slotted heads for each Node module should be tightened with a tool after both initial installation and subsequent use.
- ▶ It is recommended that the device be installed only in a server room or computer room where access is:
 - [> Restricted to qualified service personnel or users familiar with restrictions applied to the location, reasons therefore, and any precautions required.
 - [> Only afforded by the use of a tool or lock and key, or other means of security, and controlled by the authority responsible for the location.
- ▶ Please use an approved power source certified by IEC or UL. If you need an adapter, optional accessories, or further assistance, please contact ADLINK for more information.



- ▶ Lisez attentivement ces consignes de sécurité
- ▶ Conservez le manuel de l'utilisateur pour pouvoir le consulter ultérieurement
- ▶ Lisez la section Spécifications de ce manuel pour des informations détaillées sur l'environnement d'exploitation recommandé
- ▶ Lors de l'installation/montage ou de la désinstallation/retrait de l'appareil ; ou lorsque le retrait d'un boîtier est nécessaire pour l'entretien par l'utilisateur (voir Mise en route) :
 - ▶ Éteignez l'alimentation et débranchez tous les cordons/câbles d'alimentation.
 - ▶ Réinstallez tous les panneaux du boîtier avant de remettre l'alimentation sous tension.
- ▶ Pour éviter les chocs électriques et/ou d'endommager l'appareil :
 - ▶ Tenez l'appareil à l'écart de toute source d'eau ou de liquide
 - ▶ Tenez l'appareil à l'écart d'une forte chaleur ou d'une humidité élevée
 - ▶ Maintenez l'appareil correctement ventilé (n'obstruer ou ne couvrez pas les ouvertures de ventilation)
 - ▶ Utilisez toujours les réglages de tension et de source d'alimentation recommandés
 - ▶ Installez et utilisez toujours l'appareil près d'une prise de courant facilement accessible
 - ▶ Fixez le cordon d'alimentation (ne placez aucun objet sur/au-dessus du cordon d'alimentation) et connectez-le à une prise de courant avec mise à la terre
- ▶ N'essayez jamais de réparer l'appareil, qui doit être réparé uniquement par du personnel technique qualifié et utilisant des outils appropriés.
 - ▶ Lors de l'installation/montage ou de la désinstallation/retrait d'un périphérique, ou lorsque le retrait d'un couvercle de châssis est requis pour l'entretien par l'utilisateur :
 - ▶ Coupez l'alimentation et débranchez tous les cordons/câbles d'alimentation.
- ▶ Réinstallez tous les capots du châssis avant de rétablir l'alimentation. Installez/fixez et utilisez l'appareil uniquement sur des surfaces stables et/ou des supports recommandés.
- ▶ Si l'appareil n'est pas utilisé pendant une longue période, éteignez-le et débranchez-le de sa source d'alimentation.
- ▶ Une batterie de type lithium peut être fournie pour une alimentation de secours ou de secours ininterrompue.
 - ▶ L'appareil doit être réparé par des techniciens agréés lorsque :
 - ▶ Le cordon d'alimentation ou la fiche est endommagé.
 - ▶ Du liquide est entré dans l'appareil. € L'appareil a été exposé à une humidité élevée et/ou à l'humidité.
 - ▶ L'appareil ne fonctionne pas ou ne fonctionne pas conformément au manuel de l'utilisateur.
- ▶ L'appareil est tombé et/ou a été endommagé et/ou présente des signes évidents de casse.
- ▶ Débranchez le cordon d'alimentation avant de desserrer les vis moletées et fixez toujours les vis moletées avec un tournevis avant de démarrer le système.
 - ▶ L'équipement n'est pas destiné à être installé ou utilisé dans une maison, une école ou une zone publique accessible au grand public.
 - ▶ Les vis à molette avec têtes fendue pour chaque module Node doivent être serrées avec un outil après l'installation initiale et lors de l'utilisation suivante.
- ▶ Il est recommandé d'installer l'appareil uniquement dans une salle de serveurs ou une salle informatique dont l'accès est :
 - ▶ Réservé au personnel de service qualifié ou aux utilisateurs familiers avec les restrictions appliquées à l'emplacement, les raisons de celles-ci et les précautions requises.
 - ▶ Autorisé uniquement par l'utilisation d'un outil ou d'une serrure et d'une clé, ou d'autres moyens de sécurité, et contrôlé par l'autorité responsable du lieu.

Veuillez utiliser une source d'alimentation approuvée et certifiée par la norme IEC ou UL. Si vous avez besoin d'un adaptateur, d'accessoires en option ou d'une assistance supplémentaire, veuillez contacter ADLINK pour plus d'informations.

Getting Services

Ask an Expert: <https://www.adlinktech.com/en/Askanexpert>

ADLINK Technology, Inc.

Address: No. 66, Huaya 1st Road, Guishan District
Taoyuan City 333, Taiwan
Tel: +886-3-216-5088
Fax: +886-3-328-5723
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.

Address: 6450 Via Del Oro, San Jose, CA 95119-1208, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-600-1189
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.

Address: 300 Fang Chun Rd., Zhangjiang Hi-Tech Park, Pudong New Area
Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology GmbH

Address: Hans-Thoma-Strasse 8-10, 68163, Mannheim, Germany
Tel: +49-621-43214-0
Fax: +49-621 43214-30
Email: emea@adlinktech.com

Please visit the Contact page at www.adlinktech.com for information on how to contact the ADLINK regional office nearest you.