

MECS-7210

**2U Edge Computing Server
with Dual Intel® Xeon® Processor**

User's Manual



Manual Rev.:
Revision Date:
Part No.:

Rev. 1.2
June 16, 2021
50M-00013-1020

Preface

Copyright © 2021 ADLINK Technology, Inc.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Disclaimer


The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Environmental Responsibility

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive.

Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.



Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Revision History

Revision	Release Date	Description of Change(s)
1.0	2020-12-18	Initial release
1.1	2021-02-25	Update specifications; add Enter BIOS section; update MTBF
1.2	2021-06-16	Add HDD/User LED settings and commands; correct SW2 settings; update command in "3.9.1 Updating the BIOS via Network with BMC Tool"; add BIOS content

Conventions



Information to prevent minor physical injury, component damage, data loss, and/or program corruption when trying to complete a task.

Informations destinées à prévenir les blessures corporelles mineures, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche.



Information to prevent serious physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.

Informations destinées à prévenir les blessures corporelles graves, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche spécifique.

Table of Contents

Preface	2
1 Overview	6
1.1 Introduction	6
1.2 Block Diagram.....	7
1.3 Mechanical Overview	8
1.3.1 Front Panel	8
1.3.2 Rear Panel.....	8
1.3.3 Chassis Layout	9
1.4 Mechanical Dimensions	10
2 Specifications	11
2.1 MECS-7210 Specifications	11
3 Getting Started.....	13
3.1 Removing the Chassis Cover	13
3.2 Installing Memory Modules	14
3.3 PCIe Card Installation	15
3.3.1 Single-Slot-Passive Cooled PCIe Cards	15
3.3.2 Fan Cooled or Dual-Slot Passive Cooled PCIe Cards	18
3.4 PCIe x16 Slot Secondary Power Supply.....	20
3.5 Connecting the System to Ground.....	21
3.6 Login to the BMC via Console Port.....	22
3.7 Login to the BMC via Network	24
3.8 BMC eth0 Default and Static IP Settings.....	26
3.9 BIOS Update	27
3.9.1 Updating the BIOS via Network with BMC Tool.....	27
3.9.2 Updating BIOS via Host with BIOS Tool	28
3.10 BMC Firmware Update via Network.....	29
3.11 BMC Firmware Update via Host with Yafuflash.....	30
3.12 Enter BIOS Setup	31
4 System Interfaces.....	32
4.1 Status LEDs	32
4.1.1 Power LED (green).....	32
4.1.2 Alert LED (red).....	32
4.1.3 Drive Activity LED (yellow).....	32
4.2 LAN Ports.....	33
4.3 SFP+ Ports.....	34
4.3.1 SFP+ LED Behaviour	34
4.4 Dual USB 3.0 and RJ-45 Console Port.....	35
4.5 HDD/User LED Switch	36
4.6 User LED Commands	36
4.6.1 OEM ADLINK Set LED Status	36
4.6.2 OEM ADLINK Get LED Status	37
4.7 Board Layout.....	38

5 BIOS Setup.....	39
5.1 BIOS Setup Menu	39
5.1.1 Menu Selection Bar	39
5.1.2 Menu Conventions.....	40
5.2 Main Menu	40
5.2.1 BIOS Information	41
5.2.2 System Information.....	41
5.3 Advanced Menu	42
5.3.1 Sub-Menu: Serial Port Console Redirection.....	43
5.3.2 Sub-Menu: Console Redirection Settings	44
5.3.3 Sub-Menu: Legacy Console Configuration.....	46
5.3.4 Sub-Menu: Network Stack Configuration	47
5.3.5 Sub-Menu: iSCSI Configuration	48
5.3.6 Sub-Menu: Intel(R) I210 Gigabit Network Connection	49
5.3.7 Sub-Menu: NIC Configuration	50
5.4 Platform Configuration Menu	51
5.4.1 Sub-Menu: CPU Configuration	52
5.4.2 Sub-Menu: Memory Configuration.....	53
5.4.3 Sub-Menu: Memory Topology.....	55
5.4.4 Sub-Menu: UPI Configuration.....	56
5.4.5 Sub-Menu: UPI Status	58
5.4.6 Sub-Menu: Memory Error Enabling.....	59
5.4.7 Sub-Menu: PCIe Error Enabling	60
5.4.8 Sub-Menu: Socket 0/1 Configuration	62
5.4.9 Sub-Menu: PCH SATA Configuration	63
5.4.10 Sub-Menu: SATA Mode options.....	64
5.5 Server Mgmt Menu	65
5.5.1 Sub-Menu: BMC network Configuration.....	66
5.5.2 Sub-Menu: BMC User Setting	67
5.5.3 Sub-Menu: Add User	68
5.5.4 Sub-Menu: Delete User	69
5.5.5 Sub-Menu: Change User Setting.....	70
5.6 Security Menu	71
5.6.1 Sub-Menu: Secure Boot	73
5.6.2 Sub-Menu: Key Management.....	74
5.7 Boot Menu.....	75
5.8 Save & Exit Menu	77
Important Safety Instructions.....	78
Consignes de Sécurité Importantes	80
Getting Service	82

1 Overview

1.1 Introduction


The ADLINK MECS-7210 is a 2U 19" rackmount edge computing server with Intel® Xeon® Scalable processor and Intel® C620 series Chipset. The MECS-7210 features an IO intensive architecture with up to 2x PCIe x16 FHFL interfaces, 2x 2.5" SATA drive bays, 4x SFP+ ports, and is an ideal platform for 5G mobile edge computing infrastructure deployment.

The main features of the MECS-7210 are summarized as follows:


- Supports 2x FHFL PCIe x16 Gen 3 extension
- 16x DDR4 memory slots for up to 512GB memory to meet the requirement of network packet processing
- Up to 2x 2.5" external hot-swappable SATA drives, additional storage expansion via PCIe or M.2 NVMe (optional)
- Intelligent system management compatible with IPMI 2.0, supports SOL and adaptive fan speeds
- Support for PacketManager software to provide data plane software stacks for dynamic layer 3 forwarding and flow-based forwarding, accelerating development of customer applications
- Integrates Wind River® Titanium Server, and open source software including Intel® DPDK, Open vSwitch and nDPI, facilitating the building of packet parsing applications

1.3 Mechanical Overview


1.3.1 Front Panel



1.3.2 Rear Panel





1.3.3 Chassis Layout



See 3.1 *Removing the Chassis Cover* on page 13 for instructions on removing the cover.

1.4 Mechanical Dimensions

Units: mm



2 Specifications

2.1 MECS-7210 Specifications

Main System

CPU	Intel® Xeon® Silver 4116 Processor 2.10 GHz (12C/24T, 85W) Intel® Xeon® Silver 4210 Processor 2.20 GHz (10C/20T, 85W) Intel® Xeon® Silver 4214 Processor 2.20 GHz (12C/24T, 85W) Intel® Xeon® Silver 4216 Processor 2.10 GHz (16C/32T, 100W) Intel® Xeon® Gold 6130 Processor 2.10 GHz (16C/32T, 125W) Intel® Xeon® Gold 6230 Processor 2.10 GHz (20C/40T, 125W) Intel® Xeon® Gold 6238T Processor 1.90 GHz (22C/44T, 125W) Note: Please contact your ADLINK representative for other processor SKUs.
L3 Cache	From 11MB to 24.75MB, dependent on processor
Chipset	Intel® C624/C627 Chipset
Memory	16x DDR4-2666 DIMM sockets, ECC, registered, up to 512GB
BIOS	AMI BIOS on SPI flash memory
Operating System	Windows 7 64-bit, Windows 10 64-bit, Windows Server 2016, Linux Kernel 2.6 and above
Intel® QuickAssist Technology	100Gb/s Intel® QAT support (optional)
Trusted Platform Module	TPM 1.2 (TPM 2.0 optional)
Chassis Management	IPMI v2.0 compliant with iKVM and SOL support
Software Support	Validated with DPDK, provides a high throughput for data plane packet processing

Interfaces

Expansion (SKU dependent)	2x PCIe x16 Gen3 FHFL single/dual-slot interface
Ethernet	2x RJ-45 10/100/1000BASE-T Ethernet ports 4x 10G SFP+ Ethernet ports
Remote Console	1x RJ-45 serial port
USB	2x USB 3.0 (front panel) 2x USB 3.0 (internal)
Graphics	1x VGA port
LEDs	Power, Alert, Drive Activity (user programmable)

Storage

Drive Bays	2x 2.5" external hot-swappable SATA 6 Gb/s drive bays
Internal	1x onboard M.2 2242 M key SATA 6 Gb/s slot 2x M.2 2242/2280 NVMe slots (optional)

Mechanical & Environmental

Form Factor	2U 19" rackmount 438mm x 88mm x 420mm (W x H x D)
Fans	3 fans, adaptive speed
Power	800W or 1200W 1+1 redundant PSU 100V to 240V AC @50-60Hz
Temperature¹	Operating: -5°C 55°C Storage: -40°C to 70°C
Humidity¹	Operating: 10% to 85% @40°C, non-condensing Storage: 5% to 90%, non-condensing
Shock²	Operating: half-sine 2G, 11ms pulse, 100 pulses on each of three axes
	Non-operating: trapezoidal, 25G, 170 inches/sec delta V, three drops on each of three axes
Vibration	Non-operating: 2.2Grms, 10 minutes per axis on all three axes
Certifications	FCC Class A, CE emissions, UL, CB, CCC and RoHS compliant
MTBF	798789 hours @ 25°C (TBC)

Notes:

¹Temperature and humidity specifications are valid only with ADLINK approved add-on devices, excluding hard drives and PCIe cards.

²Shock and Vibration tests were conducted with WinFast RTX 2060 Super Classic graphics card installed.

3 Getting Started

3.1 Removing the Chassis Cover

Follow the instructions below to remove the chassis top cover.




CAUTION:
mise en garde

All installation procedures are restricted to qualified personnel.

Toutes les procédures d'installation sont réservées au personnel qualifié.

1. Remove the 2 screws on each side of the top cover (small arrows) and loosen the captive screw at the rear of the cover (circled).




2. Press down on the two depressions with your thumbs and slide the cover towards the rear of the chassis (large arrows). Remove the cover.

To reinstall the cover, slide it towards the front of the chassis, then replace and tighten the screws loosened and removed in Step 1.

3.2 Installing Memory Modules

When installing memory modules in the MECS-7210, the blue DIMM slots of each channel can be freely populated (it is suggested to fill the slots from “outside to inside” for each CPU). However, the black DIMM slots must be populated after the blue DIMM slots are completely filled, otherwise the device will not boot up. Please refer to the figure below.

Note: The device will not boot up if the black DIMM slots are populated before the blue DIMM slots are completely filled.



All installation procedures are restricted to qualified personnel.

Toutes les procédures d'installation sont réservées au personnel qualifié.

3.3 PCIe Card Installation

Sample installation instructions for two types of PCIe expansion cards are described below. For detailed information on the PCIe daughter board and adapter brackets required for your cards and the specific installation procedures, please contact your ADLINK representative.




All installation procedures are restricted to qualified personnel.

Toutes les procédures d'installation sont réservées au personnel qualifié.


3.3.1 Single-Slot-Passive Cooled PCIe Cards

Follow the instructions below to install single-slot-passive cooled PCIe expansion cards.


1. Remove the screw securing the bracket screw cover of the PCIe slot you wish to install an expansion card in.




2. Rotate the bracket cover clockwise and remove the screw securing the PCIe bracket blanking plate.




3. To install the single-slot-passive cooled PCIe expansion card, align the tab on the bracket with the opening on the rear I/O panel and insert the PCIe connectors into the slot on the daughter board. Make sure the connectors are fully inserted into the PCIe slot.




4. Secure the PCIe expansion card to the chassis using two screws as shown below.



5. Secure the PCIe expansion card bracket with the screw removed in Step 2, and rotate the bracket cover counter-clockwise.



6. Replace the screw securing the bracket screw cover.




7. Repeat Steps 1 through 6 to install another single-slot-passive cooled PCIe expansion card.


3.3.2 Fan Cooled or Dual-Slot Passive Cooled PCIe Cards

Follow the instructions below to install single/dual-slot fan cooled or dual-slot passive cooled PCIe expansion cards.


1. Remove the I/O bracket from the PCIe expansion card.




2. Turn the expansion card over and attach the adapter bracket with two screws.



3. If the PCIe expansion card is shorter than 312mm (full length size), attach the rear adapter bracket with two screws as shown.



4. Install the PCIe expansion card by inserting the PCIe connector into the slot on the daughter board. Make sure the connector is fully inserted into the PCIe slot.
5. Secure the PCIe expansion card to the chassis using four screws as shown below.




3.4 PCIe x16 Slot Secondary Power Supply


The power supply on the MECS-7210 is equipped with two 8-pin ATX-type 12V power connectors to provide secondary power for PCIe x16 cards if required. Two break-out cables are also included. The pin definitions of the connectors and cables are described below.

8-pin ATX-type 12V Power Connector Pinout

Pin #	Signal	Pin #	Signal
1	COM	5	+12V
2	COM	6	+12V
3	COM	7	+12V
4	COM	8	+12V



Breakout Cable Connector Pinout



Pinout

P1	P2	P3
1	1	1
2	2	2
3	3	3
4	#1	#1
	#2	#2
5	4	4
6	5	5
7	6	
8		6



CAUTION:
mise en garde

All installation procedures are restricted to qualified personnel.

Toutes les procédures d'installation sont réservées au personnel qualifié.

3.5 Connecting the System to Ground

The MECS-7210 is connected to ground by the ground pin of the 3-prong IEC power cord. Please use the power cord provided with the system for your region.

A grounding stud (M3 size) is provided on the rear of the chassis for additional connection to ground.



3.6 Login to the BMC via Console Port

Step 1

Set the Console Port to BMC mode using the 4-pole DIP Console Port Mode Switch (SW2) on the I/O board (see 1.3.3 Chassis Layout on page 9).

Pin	Default	BMC Debug
1	OFF	ON
2	ON	OFF
3	OFF	ON
4	ON	OFF


Step 2

Use the included RJ-45 to DB-9 console port adapter cable to connect the PC to the RJ-45 console port of the MECS-7210 (circled below). Refer to 4.4 *Dual USB 3.0 and RJ-45 Console Port* on page 35 for the adapter cable pin definition.




Step 3

Open a serial port console tool (such as PuTTY), choose the higher COM port (it may be different depending on your computer), then set the baud rate to 115200.



Step 3


Input the user name “sysadmin” and password “superuser” to login to the system.



3.7 Login to the BMC via Network


Step 1

Connect the LAN cable to left RJ-45 LAN port (eth0, circled below);




Step 2

Open a serial port console tool (such as PuTTY) enter the IP address, and open a connection to the BMC (login using serial console first to check the IP address).



Step 3

Input the user name “sysadmin” and password “superuser” to login to the system



The screenshot shows a PuTTY terminal window titled "10.0.0.7 - PuTTY". The window has a menu bar with "Session", "Special Command", "Window", "Logging", "Files Transfer", "Hangup", and "?". The terminal output shows the login process: "login as: sysadmin", "sysadmin@10.0.0.7's password:", and two lines of "~ #" with a green cursor on the second line. The status bar at the bottom indicates "00:00:13 Connected" and "SSH/22".

```
10.0.0.7 - PuTTY
Session Special Command Window Logging Files Transfer Hangup ?
login as: sysadmin
sysadmin@10.0.0.7's password:
~ #
~ #
```

00:00:13 Connected SSH/22

3.8 BMC eth0 Default and Static IP Settings

The default IP setting is DHCP. Users can login to the BMC to modify the IP.

Static IP Settings

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x0 0x1  
# start config
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x4 0x1  
# set IP to static mode
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x3 0xac 0x14 0x5 0xe8  
# set IP, the last four bytes is IP in hex, here is 172.20.5.232
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0xc 0x1 0x1 0x6 0xff 0xff 0xff 0x0  
#Change Mask to 255.255.255.0
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0xc 0xac 0x14 0x5 0xfe  
# set Gateway, the last four bytes, here is 172.20.5.254
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x0 0x0  
# set complete  
DHCP setting:
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x0 0x1  
# start config
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x4 0x2  
# set IP to DHCP mode
```

```
Ipmitool -I lan -H 127.0.0.1 -U admin -P admin raw 0x0c 0x01 0x01 0x0 0x0  
# set complete
```

3.9 BIOS Update

Users can update the MECS-7210 system BIOS over various interfaces (Gigabit LAN, KCS, console port).

3.9.1 Updating the BIOS via Network with BMC Tool

1. Install a Linux distribution, such as Ubuntu 14, to the debug PC.
2. Install “expect” to your debug PC (ex: sudo apt-get install expect).
3. Copy the BMC FW package “BMC_MECS-7210_Release_Vx.xx” to the debug PC;

Upgrade Procedure:

1. Check the IP of the BMC of MECS-7210. Power on the MECS-7210, boot the BMC to Linux (username: sysadmin; Passwd: superuser), and type “ifconfig” check its IP address.

```
AMI72696679006E login:
AMI72696679006E login:
AMI72696679006E login: sysadmin
Password:
login[1623]: pam_unix(login:session): session opened for user sysadmin by LOGIN(uid=0)
[1623 INFO]SERIAL Login from IP:127.0.0.1 user:sysadmin

login[1623]: [1623 INFO]SERIAL Login from IP:127.0.0.1 user:sysadmin

login[1623]: root login on 'ttyS4'
~#
~#
~#
~# ifconfig
eth0      Link encap:Ethernet  HWaddr 72:69:66:79:00:6E
          inet addr:172.20.5.77  Bcast:172.20.5.255  Mask:255.255.255.0
          inet6 addr: fe80::1009:66ff:fe79:6e/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:191 errors:0 dropped:5 overruns:0 frame:0
          TX packets:58 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:21025 (20.5 KiB)  TX bytes:8142 (7.9 KiB)
          Interrupt:2

eth1      Link encap:Ethernet  HWaddr 01:C0:A8:12:36:57
          inet6 addr: fe80::1c0:a800:112:3657/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:44 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 B)  TX bytes:10332 (10.0 KiB)
          Interrupt:3
```

2. On the debug PC, execute the following commands to perform the upgrade.

```
cd BMC_MECS-7210_Release_Vx.xx
```

```
cd BIOS
```

```
./adlinktool.sh upgradebios1 BIOS_xxxx.bin 172.20.5.77
```

Note: Only “bin” files are supported when updating the BIOS via Network.

3.9.2 Updating BIOS via Host with BIOS Tool

1. Boot/Login to Shell
2. Update the BIOS over host with the following commands.

Example:

AfuEfix64 BIOS.ROM /p /b /n /k (to update BIOS without ME)

AfuExfi64 BIOS.BIN /p /b /n /k /me (to update the entire BIOS)

```
fs0:\MECS7210> dir
Directory of: fs0:\MECS7210

04/06/20  05:44p <DIR>                4,096  .
04/06/20  05:44p <DIR>                 0  ..
01/14/20  03:22p                505,968  AfuEfix64.efi
01/14/20  03:22p                7,360  HISTORY.txt
01/14/20  03:22p           33,554,432  MECS-7210_00210.BIN
01/14/20  03:22p          16,777,216  MECS-7210_00210.ROM
01/14/20  03:22p                402  pBIOS.nsh
02/14/20  04:04p                403  pSPI.nsh
        6 File(s)  50,845,781 bytes
        2 Dir(s)

fs0:\MECS7210> _
```

3.10 BMC Firmware Update via Network

The MECS-7210 supports a BMC Chassis Management firmware, IPMI v2.0 compliant. To install the BMC firmware via network, perform the following steps.

1. Install a Linux distribution, such as Ubuntu 14, to the debug PC.
2. Install “expect” to your debug PC (ex: sudo apt-get install expect).
3. Copy the BMC FW package “BMC_MECS-7210_Release_Vx.xx” to the debug PC;

Upgrade Procedure:

1. Check the IP of the BMC of MECS-7210. Power on the MECS-7210, boot the BMC to Linux (username: sysadmin; Passwd: superuser), and type “ifconfig” check its IP address.

```
AMI72696679006E login:
AMI72696679006E login:
AMI72696679006E login: sysadmin
Password:
login[1623]: pam_unix(login:session): session opened for user sysadmin by LOGIN(uid=0)
[1623 INFO]SERIAL Login from IP:127.0.0.1 user:sysadmin

login[1623]: [1623 INFO]SERIAL Login from IP:127.0.0.1 user:sysadmin

login[1623]: root login on 'ttyS4'
#
#
#
#
# ifconfig
eth0      Link encap:Ethernet  HWaddr 72:69:66:79:00:6E
          inet addr:172.20.5.77  Bcast:172.20.5.255  Mask:255.255.255.0
          inet6 addr: fe80::7069:66ff:fe79:6e/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:191 errors:0 dropped:5 overruns:0 frame:0
          TX packets:58 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:21025 (20.5 KiB)  TX bytes:8142 (7.9 KiB)
          Interrupt:2

eth1      Link encap:Ethernet  HWaddr 01:C0:A8:12:36:57
          inet6 addr: fe80::1c0:a800:112:3657/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:44 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 B)  TX bytes:10332 (10.0 KiB)
          Interrupt:3
```

2. On the debug PC, execute the following commands to perform the upgrade.

```
cd BMC_MECS-7210_Release_Vx.xx
cd FW
./adlinktool.sh bmc1 rom.ima 172.20.5.77
```

3.11 BMC Firmware Update via Host with Yafuflash

The MECS-7210 supports a BMC Chassis Management firmware, IPMI v2.0 compliant. To update the BMC firmware via host with Yafuflash, perform the following steps.

1. Login to the OS with root user permission.
2. Update the BMC over host using the commands below:

Example:

```
$ sudo ./Yafuflash -kcs rom.ima
```

```
YAFUFlash - Firmware Upgrade Utility (Version 4.117.7)
```

```
-----  
(C)Copyright 2016, American Megatrends Inc.  
The Module root allocated size is different from the one in the Image  
So,Type (Y/y) to do Full Firmware Upgrade or (N/n) to exit  
Enter your Option : Y
```

```
*****  
WARNING!  
FIRMWARE UPGRADE MUST NOT BE INTERRUPTED ONCE IT IS STARTED.  
PLEASE DO NOT USE THIS FLASH TOOL FROM THE REDIRECTION CONSOLE.  
*****
```

```
Uploading Firmware Image : 100%... done  
Skipping [boot] Module ....  
Flashing [conf] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Flashing [root] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Flashing [osimage] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Flashing [www] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Flashing [testapps] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Flashing [ast2500e] Module ....  
Flashing Firmware Image : 100%... done  
Verifying Firmware Image : 100%... done  
Resetting the firmware.....
```

```
-----  
Open IPMI Drivers
```

```
-----  
Loading Open IPMI Driver:ipmi_devintf  
BMC is booting up, Please load ipmi_si Open IPMI Driver after the BMC  
Boots up!!!!  
Loading Open IPMI Driver:ipmi_msghandler
```

3.12 Enter BIOS Setup


To enter the BIOS setup screen, follow these steps:

1. Power on the MECS-7210.
2. Press the <Delete> or <ESC> key on your keyboard when you see the following text prompt: "Press DEL or ESC to enter Setup" .
(Note: If Quick Boot is enabled, the screen below will not display, but pressing the <Delete> or <ESC> key will still allow you to enter the BIOS setup screen.)



3. After pressing the <Delete> or <ESC> key, the main BIOS setup menu will display. You can access the other setup screens from the main BIOS setup menu, such as Chipset and Power menus.

4 System Interfaces



4.1 Status LEDs

4.1.1 Power LED (green)

The Power LED will light in boot up state.

4.1.2 Alert LED (red)

The LED will light when a BIOS failure is detected or a sensor reading exceeds its upper/lower un-recoverable threshold.


4.1.3 Drive Activity LED (yellow)

The Drive Activity (HDD) LED is controlled by SATALED# from the chipset. When SATA storage is active (read/write), the LED will blink.

Note: This LED can also be user defined. Refer to 4.5 HDD/User LED and 4.6 User LED Commands on page 36.

4.2 LAN Ports

Pin #	Signal
1	MDI_P0
2	MDI_N0
3	MDI_P1
4	MDI_N1
5	MDI_P2
6	MDI_N2
7	MDI_P3
8	MDI_N3



LAN LED Behaviour

The LAN LEDs are integrated into the RJ-45 connector. Their behavior is as follows:


LED1 (Speed)	
10 Mbps	Off
100 Mbps	Green
1000 Mbps	Orange

The LED2 (Link/Activity) indicates that a link has been established by lighting orange. When data is transmitted the LED blinks orange.


LED2 (Link/Activity)	
Link with no activity	Steady
Link with activity	Blinking

4.3 SFP+ Ports

Pin	Signal Name
1	GND
2	TX_FAULT
3	TX_DSBL
4	SDA
5	SCL
6	MOD_ABS
7	RS0
8	RX_OS
9	RS1
10	GND
11	GND
12	RD-
13	RD+
14	GND
15	VCCR
16	VCCT
17	GND
18	TX+
19	TX-
20	GND



4.3.1 SFP+ LED Behaviour




The LEDs point to the respective port.


LED	Status	Behavior
Link Status	Link up	Yellow (steady)
	Link down	Off
Link Activity	Active	Green (blinking)
	Not active	Off

4.4 Dual USB 3.0 and RJ-45 Console Port

Pin	Signal Name
R1	N/C
R2	N/C
R3	COM_TXD
R4	GND
R5	GND
R6	COM_RXD
R7	N/C
R8	N/C
U1	5V
U2	USB2_N
U3	USB2_P
U4	GND
U5	SSRX_N
U6	SSRX_P
U7	GND
U8	SSTX_N
U9	SSTX_P
U10	5V
U11	USB2_N
U12	USB2_P
U13	GND
U14	SSRX_N
U15	SSRX_P
U16	GND
U17	SSTX_N
U18	SSTX_P



The MECS-7210 comes with an RJ-45 to DB-9 console port adapter cable.




DB-9 Pin	Signal
1	—
2	RXD
3	TXD
4	DTR
5	SG
6	DSR
7	RTS
8	CTS
9	—

4.5 HDD/User LED Switch

The HDD/User LED Switch (SW1) can be used to set the function of the Drive Activity LED (default is Drive Activity).

LED Function	Pin 1	Pin 2
HDD Activity	ON	OFF
User Defined	OFF	ON

The HDD/User LED Switch (SW1) is located under the SATA drive bays as shown below. Remove the SATA Drive Bays and open the chassis cover to access SW1 (see 3.1 *Removing the Chassis Cover* on page 13).



4.6 User LED Commands

4.6.1 OEM ADLINK Set LED Status

NetFn=2Eh, Cmd=10h

Byte	Data Field
1~3	ADLINK Manufacturer ID –005F13h, LS byte first.
4	LED ID: 01h= Alert LED (red) 02h = App LED (yellow) Other values: reserved
5	LED Function: 00h = LED OFF override.


Byte	Data Field
	01h - 1Eh = LED BLINKING override. The off duration is specified by the value of this byte, and the on duration is specified by the value of byte 5. Both values specify the time in hundreds of milliseconds (100 ms-3 s). 1Fh = LED state is restored to Local Control state 20h-FEh Reserved FF = LED ON override
6	On-duration: The LED on-time in hundreds of milliseconds if (01h Byte 6 1Eh) and ignored otherwise. Otherwise, this field is ignored and is set to 0h.
Response Field	
1	Completion Code
2-4	ADLINK Manufacturer ID – 005F13h, LS byte first.

4.6.2 OEM ADLINK Get LED Status

NetFn=2Eh, Cmd=11h

Byte	Data Field
1-3	ADLINK Manufacturer ID – 005F13h, LS byte first.
4	LED ID: 01h= Alert LED (Red) 02h = App LED (Yellow) Other values: reserved
Response Field	
1	Completion Code
2-4	ADLINK Manufacturer ID D of ran, LS byte first.
5	LED ID: 01h= Alert LED (Red) 02h = App LED (Yellow) Other values: reserved
6	LED Function: 00h = LED OFF override. 01h - 1Eh = LED BLINKING override. The off duration is specified by the value of this byte, and the on duration is specified by the value of byte 7. Both values specify the time in hundreds of milliseconds (100 ms-3 s). 1Fh = LED is in Local Control state 20h-FEh Reserved FF = LED ON override
7	On-duration : The LED on-time in hundreds of milliseconds if (01h Byte 6 1Eh) and ignored otherwise set to 0h.

4.7 Board Layout



A	CPU0	G	PCIe x8 slot
B	CPU1	H	SATA Port
C	PCH	I	NIM slot
D	BMC Chip	J	PWR CONN
E	CPLD Chip	K	B2B for Daughter Board
F	DDR4 DIMM		

5 BIOS Setup

5.1 BIOS Setup Menu

The BIOS setup utility is invoked by pressing <ESC> or keys. User can change BIOS settings during setup utility runs. A system reset is required for new settings to take effect.

In the BIOS setup utility, there are several hot keys are designed for specific purposes, as listed below.

- <F1>: General help in setup menu
- <F8>: Load previous BIOS values
- <F9>: Load BIOS default in setup utility
- <F10>: Save & Exit setup utility

To navigate through the BIOS setup menu, use the following.

→←	Left/Right. The <i>Left and Right</i> < Arrow > keys allow you to select a setup screen. For example: Main screen, Advanced screen, Chipset screen, and so on.
↑↓	Up/Down The <i>Up and Down</i> < Arrow > keys allow you to select a setup item or sub-screen.
+ -	Plus/Minus The <i>Plus and Minus</i> < Arrow > keys allow you to change the field value of a particular setup item. For example: Date and Time.
Tab	The < Tab > key allows you to select setup fields.

5.1.1 Menu Selection Bar

The Menu Selection Bar is located at the top of the screen. It displays the top level available menus to the user:

- Main Menu
- Advanced Menu
- Platform Configuration Menu
- Server Mgmt
- Security Menu
- Boot Menu
- Save & Exit Menu

5.1.2 Menu Conventions

The appearance of the setup menu listed in this chapter is a sample to describe the item list. It is shown on a VT100 terminal via serial console. The menu conventions are as follows.

Using color

The mandatory BIOS setup fields are in black. The BIOS setup fields currently not used are in grey. The display only strings are in black.

Using brackets

Editable menu options are marketed with squares '[' and ']' to distinguish them from display only fields that can't be modified.

5.2 Main Menu

The Main Menu provides read-only information about the system and also allows you to set the system date and time. The tables below show screen shots of the Main menu details, submenus and settings.

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.						
Main	Advanced	Platform Configuration	Server Mgmt	Security	Boot	Save & Exit
BIOS Information				Set the Date. Use Tab to switch between Date elements.		
BIOS Vendor		American Megatrends				
Core Version		5.14				
Compliance		UEFI 2.7; PI 1.6				
BIOS Version		MECS-7120 0.07.10				
Build Date		07/29/2020				
MRC Version		0584.D01				
SPS FW Version		0A:4.1.4.296				
System Information						
Project Name		MECS-7210				
CPU 0 Brand String		Intel(R) Xeon(R) Gold 5218 CPU @2.30GHz				
CPU 1 Brand String		Intel(R) Xeon(R) Gold 5218 CPU @2.30GHz				
CPU Frequency		2300 MHz				
Total Memory		16384 MB (DDR4)		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit		
Memory Frequency		2132 MHz				
PCH SKU		LBG QS/PRQ – 1G(S0)				
System Date		[Thu 04/23/2018]				
System Time		[16:28:59]				
Access Level		Administrator				
Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.						

5.2.1 BIOS Information

BIOS Item	Options	Description
BIOS Vendor	Info-only. American Megatrends	Display vendor name of system BIOS.
Core Version	Info-only x.yy	Display core version of booting BIOS.
Compliance	Info-only UEFI 2.7; PI 1.6	Display compliance of booting BIOS
BIOS Version	Info-only. x.yy.zz	Display version of booting BIOS.
Build Date	Info-only. MM/DD/YYYY	It shows the date that BIOS was built.
MRC Version	Info-only. xxx.Ryy	Display the revision of MRC code which is implemented in BIOS.
SPS FW Version	Info-only. ww:x.y.z.aaa	Display the version of Intel manageability firmware which is implemented in BIOS.

5.2.2 System Information

BIOS Item	Options	Description
Project Name	Info-only. MECS-7210	It shows project name.
CPU 0/1 Brand String	Info-only. Intel(R) Xeon ...	It shows what CPU is booting the system.
CPU Frequency	Info-only. XXXX MHz	It shows CPU's frequency.
Total Memory	Info-only. XXXX MB (DDR4)	It shows total memory size used on the motherboard and memory type.
Memory Frequency	Info-only. XXXX MHz	It shows memory's frequency.
PCH SKU	Info-only. LBG xxxxx	It shows what PCH SKU is designed on motherboard.
System Date	MM/DD/YYYY	For configuring/showing system date. When setting the Date, use <Tab> key to switch between Date elements.
System Time	HH:MM:SS	For configuring/showing system time. When setting the Time, use <Tab> key to switch between Time elements.
Access Level	Info-only. Administrator/User	It shows what access level is used to enter BIOS setup menu.

5.3 Advanced Menu

This menu contains the settings for most of the user interfaces in the system.

The screenshot displays the Aptio Setup Utility BIOS interface. At the top, the title bar reads "Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.". Below the title bar, a navigation menu is visible with the following options: Main, **Advanced**, Platform Configuration, Server Mgmt, Security, Boot, and Save & Exit. The main content area is divided into two sections by a dashed line. The left section, titled "Above 4G Decoding [Disabled]", contains a list of options: "> Serial Port Console Redirection", "> Network Stack Configuration", "> iSCSI Configuration", "> Intel(R) I210 Gigabit Network Connection – 00:E0:18:07:", and "> Intel(R) I210 Gigabit Network Connection – 00:E0:18:08". The right section, titled "Network Stack Settings", contains a list of instructions: "><: Select Screen", "^v: Select Item", "Enter: Select", "+/-: Change Opt.", "F1: General Help", "F8: Previous Values", "F9: Optimized Default", "F10: Save & Exit", and "ESC: Exit". At the bottom of the screen, the version information "Version 2.19.1268, Copyright (C) 2017 American Megatrends, Inc." is displayed.

BIOS Item	Options	Description
Above 4G Decoding	Disabled Enabled	The definition of “Above 4G decoding” is to allow the user to enable or disable memory-mapped I/O for a 64-bit PCIe device to 4GB or greater address space
Serial Port Console Redirection	Sub-Menu	For configuring serial console.
Network Stack Configuration	Sub-Menu	For configuring Network Stack.
iSCSI Configuration	Sub-Menu	For iSCSI Configuration.
Intel(R) I210 Gigabit Network Connection - ...	Sub-Menu	Onboard Ethernet controller configuration loaded by EFI driver. The setup page designed by Intel and when running Ethernet EFI driver, this page will be shown. It is related to “Network” setting in Boot setup page.

5.3.1 Sub-Menu: Serial Port Console Redirection

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Advanced

COM0 Console Redirection [Enabled] > Console Redirection Settings Legacy Console Redirection > Legacy Console Redirection Settings Serial Port for Out-of-Band Management/ Windows Emergency Management Services (EMS) Console Redirection [Disabled] > Console Redirection Settings		Console Redirection Enable or Disable. ><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit
--	--	---

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Console Redirection	Enabled Disabled	Enable or disable serial port console redirection function.
Console Redirection Settings	Sub-Menu	For configuring serial port settings when console redirection function is enabled.
Legacy Console Redirection Settings	Sub-Menu	For configuring Legacy Console Redirection Settings

5.3.2 Sub-Menu: Console Redirection Settings

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Advanced

Console Redirection Settings		Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more
Terminal Type	[VT100+]	
Bits per second	[115200]	
Data Bits	[8]	
Parity	[None]	
Stop Bits	[1]	
Flow Control	[None]	
VT-UTF8 combo key support	[80x24]	
Recorder	[Enable]	
Resolution 100x31	[Disabled]	
Putty KeyPad	[Disabled]	
	[VT100]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	Configure the type of console emulation. Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600 19200 38400 57600 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speed.
Data Bits	7 8	Configure the number of data bits in each transmitted or received serial character for both serial ports.
Parity	None Even Odd Mark	Configures if parity bit is generated (transmit data) or checked. A parity bit can be sent with the data bits to

BIOS Item	Options	Description
	Space	detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark: parity bit is always 1. Space: Parity bit is always 0. Mark and Space Parity do not allow for error detection. They can be used as an additional data bit.
Stop Bits	1 2	Configures the number of stop bits transmitted and received in each serial character for both serial ports. Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
Flow Control	None Hardware RTS/CTS	Configures flow control for console redirection. Hardware flow control uses RTC/CTS.
VT-UTF8 combo key Support	Enable Disable	Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Enable Disable	With this mode enabled only text will be sent. This is to capture Terminal data.
Resolution 100x31	Enable Disable	Enables or disables extended terminal resolution
Putty KeyPad	VT100	Select FunctionKey and KeyPad on Putty.

5.3.3 Sub-Menu: Legacy Console Configuration

Aptio Setup Utility – Copyright © 2020 American Megatrends, Inc.

Advanced

Legacy Console Redirection Settings	
Redirection COM Port	[COM0]
Redirection	[80x24]
Redirection After POST	[Always Enable]

Select a COM port to display redirection of Legacy OS and Legacy OPRM Message

><: Select Screen
 ^v: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F8: Previous Values
 F9: Optimized Default
 F10: Save & Exit
 ESC: Exit

Version 2.20.1275. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
Redirection COM Port	COM0	Select a COM port to display redirection of Legacy OS and Legacy OPRM Messages
Redirection	80X24 80X25	On Legacy OS, the Number of Rows and Columns supported redirection
Redirection After POST	Always Enable BootLoader	When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. Default setting for this option is set to Always Enable.

5.3.4 Sub-Menu: Network Stack Configuration

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Advanced

Network Stack Configuration		Enable/Disable UEFI Network Stack
Network Stack	[Enabled]	
Ipv4 PXE Support	[Enabled]	
Ipv6 PXE Support	[Enabled]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Network Stack Configuration	Info-only	
Network Stack	Disabled Enabled	To enable or disable network stack.
IPv4 PXE Support	Disabled Enabled	To enable or disable IPv4 PXE boot.
IPv6 PXE Support	Disabled Enabled	To enable or disable IPv6 PXE boot.

5.3.5 Sub-Menu: iSCSI Configuration

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Advanced

iSCSI Initiator Name	The worldwide unique Name of iSCSI Initiator. Only IQN Format is accepted. Range is from 4 to 223
> Add an Attempt	
> Delete Attempts	
> Change Attempt Order	
	><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
iSCSI Initiator Name	Info-only	
Add an Attempt	Sub-Menu	To Add an Attempt for MAC Selection if it's available.
Delete Attempts	Sub-Menu	To Delete Attempts if it's available.
Change Attempt Order	Sub-Menu	To Change Attempt Order if it's available.

5.3.6 Sub-Menu: Intel(R) I210 Gigabit Network Connection

This setup page is shown when “Network” setting in Boot page is set to “UEFI”. When the BIOS boots the system, it will launch the onboard Ethernet I210 controller’s UEFI driver. The driver provides a setup page for configuring Ethernet parameters and shows information about Ethernet controller. When the Ethernet’s UEFI driver is not executed, this setup page will not be shown.

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Advanced

> NIC Configuration		Click to configure the network device port.
Blink LEDs	0	
UEFI Driver	Intel(R) PRO/1000 6.7...	
Adapter PBA	000300-000	
Device Name	Intel(R) I210 Gigabit...	
Chip Type	Intel i210	
PCI Device ID	1533	
PCI Address	03:00:00	
Link Status	[Disconnected]	
MAC Address	00:E0:18:07:18:00	><: Select Screen
Virtual MAC Address	00:00:00:00:00:00	^v: Select Item
		Enter: Select
		+/-: Change Opt.
		F1: General Help
		F8: Previous Values
		F9: Optimized Default
		F10: Save & Exit
		ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
NIC Configuration	Sub-Menu	For configuring link speed and wake function.

5.3.7 Sub-Menu: NIC Configuration

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Advanced

Link Speed Wake On LAN	[Auto Negotiated] [Enabled]	Specifies the port speed used for the selected boot protocol.
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Link Speed	Auto Negotiated 10 Mbps Half 10 Mbps Full 100 Mbps Half 100 Mbps Full	For setting link speed of Ethernet.
Wake On LAN	Enabled Disabled	For enabling/disabling wake on LAN function.

5.4 Platform Configuration Menu

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.					
Main	Advanced	Platform Configuration	Server Mgmt	Security	Boot Save & Exit
> CPU Configuration > Memory Configuration > UPI Configuration > Memory Error Enabling > PCIe Error Enabling >Socket0 Configuration >Socket1 Configuration >PCH SATA Configuration SR-IOV Support [Enable] Intel© VT for Directed I/O (VT-d) [Enable] Automatic Board Power Up [On]				CPU Configuration parameters ><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit	
Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.					

BIOS Item	Options	Description
CPU Configuration	Sub-Menu	For configuring CPU features/functions.
Memory Configuration	Sub-Menu	For configuring memory features and functions.
UPI Configuration	Sub-Menu	For configuring UPI features and functions.
Memory Error Enabling	Sub-Menu	For configuring memory error assertion settings.
PCIe Error Enabling	Sub-Menu	For configuring PCIe error assertion settings.
Socket0 Configuration	Sub-Menu	For configuring Socket0 features and functions.
Socket1 Configuration	Sub-Menu	For configuring Socket1 features and functions.
PCH SATA Configuration	Sub-Menu	For SATA operating mode setting.
SR-IOV Support	Disable Enable	For enabling/disabling SR-IOV Support.
Intel® VT for Directed I/O (VT-d)	Disable Enable	For enabling/disabling Intel VT-d function.
Automatic Board Power Up	On Off	Select 0m/Off for ACPI state after a G3

5.4.1 Sub-Menu: CPU Configuration

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Platform
Configuration

CPU Configuration		Enable/Disable Hyper-Threading
Hyper-Threading	[Enable]	
Execute Disable Bit	[Enable]	
VMX	[Disable]	
Enable Intel(R) TXT	[Disable]	
Numa	[Enable]	
Hardware Prefetcher	[Enable]	
SpeedStep (Pstates)	[Enable]	
Turbo Mode	[Enable]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
CPU Configuration	Info-only	
Hyper-Threading	Enable Disable	To enable or disable hyper-threading function of CPU.
Execute Disable Bit	Disable Enable	Execute Disable Bit can help prevent certain classes of malicious buffer overflow attacks. OS and application installed must support this feature in order for it is enabled.
VMX	Disable Enable	To enable or disable Virtual-Machine Extensions of CPU.
Enable Intel(R) TXT	Disable Enable	Enable or disable Intel(R) TXT function.
Numa	Disable Enable	For enabling or disabling Numa function.
Hardware Prefetcher	Disable Enable	To enable or disable hardware prefetcher of CPU.
SpeedStep (P-states)	Disable Enable	To enable or disable Speedstep function of CPU.
Turbo Mode	Disable Enable	To enabled or disable Turbo Mode of CPU.

5.4.2 Sub-Menu: Memory Configuration

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

Memory Configuration		Displays memory topology with Dimm population information
> Memory Topology		
Memory Frequency	[Auto]	
Channel Interleaving	[Auto]	
Rank Interleaving	[Auto]	
ADDDC Sparing	[Disable]	
Patrol Scrub	[Enable]	
Patrol Scrub Interval	24	
Patrol Scrub Address	[System Physical Addr]	
Data Scrambling	[Disable]	
Volatile Memory Mode	[1LM]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
Memory Configuration	Info-only	
Memory Topology	Sub-Menu	To display memory topology with DIMM's population information.
Memory Frequency	Auto 1866 2133 2400 2666	Use this item to set the maximum memory frequency for onboard memory modules.
Channel Interleaving	Auto 1-way Interleave 2-way Interleave 3-way Interleave	Channel interleaving divide memory blocks and spread contiguous portions of data across interleaved channels. It increases potential read bandwidth as requests for data can be made to all interleaved channels in an overlapped manner. Enable channel interleaving is possible to enhance the performance.
Rank Interleaving	Auto	The interleaving is performed on rank

BIOS Item	Options	Description
	1-way Interleave 2-way Interleave 4-way Interleave 8-way Interleave	to have different bandwidth.
ADDDC Sparing	Disable Enable	It is to enable/disable ADDDC sparing. NOTE: it can't be enabled when mirror mode is enabled or memory sparing is enabled.
Patrol Scrub	Disable Enable	When setting, Enable is set to this option, patrol scrub is initialized to read through all of memory in an interval hour period which is gotten from "Patrol Scrub interval" option. Patrol scrub will correct any correctable error correction code (ECC) errors it encounters by writing back the corrected data to memory.
Patrol Scrub Interval	24	Hour-based setting for the interval of patrol scrub. NOTE: this option will be hidden when "Patrol Scrub" is disabled.
Patrol Scrub Address	Reverse Address System Physical Address	This is a feature for configuring the mode of Patrol scrub. When "System Physical Address" is set, patrol runs in system address generation mode. If it is set to "Reverse Address", patrol will run in legacy mode. NOTE: this option will be hidden when "Patrol Scrub" is disabled.
Data Scrambling	Disable Enable Auto	Enable it to enhance system performance and data integrity.
Volatile Memory Mode	1LM 2LM Auto	Configure "volatile memory mode" to one-level memory mode or two-level memory mode.

5.4.3 Sub-Menu: Memory Topology

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

Socket0.ChD.Dimm0 :
2132MT/s SRx4 16GB RDIMM
Socket0.ChE.Dimm0 :
2132MT/s SRx4 16GB RDIMM
Socket0.ChF.Dimm0 :
2132MT/s SRx4 16GB RDIMM

><: Select Screen
^v: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F8: Previous Values
F9: Optimized Default
F10: Save & Exit
ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
Socket X .Ch Y .Dimm Z :	Info-only	The information shows only when memory is present in the DIMM slot. It is the information of DIMM slot's location and X, Y and Z indicate which slot has memory plugged. X = 0/1 – CPU0/CPU1 Y = Channel A/B/C/D/E/F of CPU0 or Channel G/H/J/K/L/M of CPU1 Z will always be 0 because hardware design only supports one DIMM per channel. Regarding to the topology, please refer to section 2.2 – Memory initialization.
[Memory Frequency] [Rank number] [Memory size] [Memory type]	Info-only	It is the information of memory frequency, type and size which varies by what memory is plugged. For example: 2132MT/s SRx4 16GB RDIMM It means 16GB registered DIMM with 2133MT/s frequency is operating at 1 single rank x4 configuration.

5.4.4 Sub-Menu: UPI Configuration

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

UPI Configuration	UPI Status Help
> UPI Status Link Speed Mode [Fast] Link Frequency Select [Auto] KTI Prefetch [Enable] Stale AtoS [Disable] LLC dead line alloc [Enable]	><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
UPI Configuration	Info-only	
UPI Status	Sub-Menu	To show the current UPI status includes number of CPU, IIO and UPI link speed and frequency.
Link Speed Mode	Slow Fast	For configure UPI link speed. UPI speed mode should be 'Slow' when there only has one processor installed because UPI is not functional. Set 'Slow' for multi-processor only when it wants UPI to run at the boot speed of 50 MT/s.
Link Frequency Select	9.6GT/s 10.4GT/s Auto Use Per Link Setting	For selecting UPI link frequency. When there is only one processor, setting of this item will not be functional and status of link frequency will be unknown or 1S configuration.
KTI Prefetch	Disable Enable	It is for enabling/disabling KTI prefetch function.
Stale AtoS	Disable	The in-memory directory has three states:

BIOS Item	Options	Description
	Enable Auto	invalid (I), snoopAll (A), and Shared (S). The snoopAll (A) means the data may exist in another socket or modified state. Shared (S) state means the data may be shared across one or more socket's caches. When reading memory and directory line is in the A state, we must snoop all the other sockets because another socket may have the line in modified state. If this is the case, the snoop will return the modified data. However, it may be the case that all snoops come back a miss if another socket read the line earlier and then dropped it from its cache without modifying it. Disable – allows processing memory directory states as described above. Enable – where a line in A state returns only snoop misses, the line will be transition to S state. Subsequent reads to the line will encounter it in S state and not have to snoop, saving latency and snoop bandwidth.
LLC dead line alloc	Disable Enable Auto	In CPU cache scheme, mid-level cache (MLC) evictions are filled into last-level cache (LLC). When lines are evicted from MLC, core can flag them as "dead". This means that lines are not likely to be read again. This option allows dropping dead line and never fills them into LLC if the option is disabled. When it is enabled, the LLC can opportunistically fill dead lines into LLC if space is available.

5.4.5 Sub-Menu: UPI Status

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

UPI Status	
Number of CPU	1
Number of IIO	1
UPI Link Speed	Slow or 1S
UPI Link Frequency	Unknown or 1S

><: Select Screen
 ^v: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F8: Previous Values
 F9: Optimized Default
 F10: Save & Exit
 ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
UPI Status	Info-only	
Number of CPU	Info-only	Shows how many CPUs are using on system.
Number of IIO	Info-only	Shows how many IIOs are using on system.
UPI Link Speed	Info-only	Shows current UPI speed (fast/slow).
UPI Link Frequency	Info-only	Shows current UPI link frequency (9.6 GT/s or 10.4 GT/s).

5.4.6 Sub-Menu: Memory Error Enabling

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

Memory Error Enabling		Enable/Disable Memory Error
Memory Error	[Enable]	
Mem Corrected Error	[Enable]	
Error Threshold	3e8	
Leaky bucket low bit	28	
Leaky bucket high bit	29	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
Memory Error Enabling	Info-only	
Memory Error	Disable Enable	This is used to enable/disable memory error handling.
Mem Corrected Error	Disable Enable	This is used to enable/disable memory correctable error handling.
Error Threshold	1000	Rank sparing enables a failing rank to be replaced by an unused spare rank installed on the same DDR channel. The failure prediction is done via corrected error threshold and a leaky bucket , both of which are programmable to allow the platform to “judge” when the right time is to spare a failing rank. The value set in this item will be set to correctable error threshold used for error handling.
Leaky bucket low bit	40	Value range: 1 – 41 It is to set low bit for the leaky bucket algorithm which is used to check the data transmissions between CPU sockets and the memory controller.
Leaky bucket high bit	41	Value range: 1 – 41

BIOS Item	Options	Description
		It is to set high bit for the leaky bucket algorithm which is used to check the data transmissions between CPU sockets and the memory controller.

5.4.7 Sub-Menu: PCIe Error Enabling

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

PCIe Error Enabling		Enable & escalate Correctable Errors to error pins.
Corrected Error	[Enable]	
PCIE Corrected Error	[Enable]	
Error Threshold Mask	3f	
Error Threshold	1	
Uncorrected Error	[Enable]	
Fatal Error Enable	[Enable]	
AER Corrected Error	[Enable]	
AER Advisory Nonfatal	[Enable]	
AER NonFatal Error	[Enable]	
AER Fatal Error	[Enable]	
SERR Propagation	[Enable]	
PERR Propagation	[Enable]	
Signal to OS on SERR	[Enable]	
Signal to OS on PERR	[Enable]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
PCIe Error Enabling	Info-only	
Corrected Error	Disable Enable	It is used to enable/disable PCIe correctable error monitoring and handling.
PCIE Corrected Error	Disable Enable	It is used to enable/disable PCIe correctable error counter.
Error Threshold Mask	0x3F	This is for setting what errors will be included in error count. (Bit 0 – Bit 5) Bit 0 – receiver error Bit 1 – Bad TLP Bit 2 – Bad DLLP Bit 3 – replay num rollover Bit 4 – Replay Timer Timeout Bit 5 – Advisory non-fatal
Error Threshold	1	It is for setting the threshold of PCIe correctable error counter.
Uncorrected Error	Disable	It is for enabling/disabling the escalation

BIOS Item	Options	Description
	Enable	of uncorrectable event to error pins.
Fatal Error Enable	Disable Enable	It is for enabling/disable the escalation of PCIe fatal errors to error pins.
AER Corrected Error	Disable Enable	For enabling or disabling PCIe AER correctable error reporting.
AER Advisory Nonfatal	Disable Enable	For enabling or disabling PCIe AER Advisory Non-fatal error reporting.
AER NonFatal Error	Disable Enable	For enabling or disabling PCIe AER Non-fatal error reporting.
AER Fatal Error	Disable Enable	For enabling or disabling PCIe AER fatal error reporting.
SERR Propagation	Disable Enable	When PCI express root port detects an error, it will bring down the PCIe link associated with the affected root port within one cycle and then SMM handler restores the link. PCIe LER (live error recovery) prevents the transfer of associated corrupt data during process, trapping errors at a root port to prevent their propagation. This option is to enable/disable the prevention of SERR propagation.
PERR Propagation	Disable Enable	This option is to enable/disable the prevention of PERR propagation.
Signal to OS on SERR	Disable Enable	It is used for notifying OS on receiving SERR event.
Signal to OS on PERR	Disable Enable	It is used for notifying OS on receiving PERR event.

5.4.8 Sub-Menu: Socket 0/1 Configuration

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

Memory Error Enabling	Enable/Disable Memory Error
Daughter Board PCIe(IOU2 IIO PCIe BR3) [x16]	
	><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
Daughter Board PCIe(IOU2 IIO PCIe BR3)	X16 X8	Selects PCIe port Bifurcation for selected slot(s)

5.4.9 Sub-Menu: PCH SATA Configuration

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

PCH SATA Configuration		CPU Configuration parameters
SATA Controller	[Enable]	
Configure SATA as	[AHCI]	
SATA test mode	[Disable]	
>SATA Mode options		
Support Aggressive Link Power Management	[Enable]	
SATA Port 0		
Port 0	[Enable]	
Hot Plug	[Disable]	
Configure as eSATA	[Disable]	
Spin up Device	[Disable]	
sSTS Device Type	[Hard Disk Drive]	
SATA Topology	[Unknown]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
SATA Controller	Disable Enable	For controlling SATA controller's enabling/disabling.
Configure SATA as	AHCI RAID	For SATA operating mode setting.
SATA test mode	Disable Enable	Enable/Disable SATA test mode
SATA Mode option	Sub-Menu	SATA mode related option
Support Aggressive Link Power Management	Disable Enable	Enables/Disables SALP
Port 0	Disable Enable	Enable or Disable SATA Port
Hot Plug	Disable Enable	Designates this port as Hot Pluggable
Configure as eSATA	Disable Enable	Configures port as External SATA (eSATA)
Spin up Device	Disable Enable	If enabled for any of ports Staggered Spin Up will be performed and only the drives witch have this option enabled will spin up at boot. Otherwise all drives spin up at boot.

BIOS Item	Options	Description
SATA Device Type	Hard Disk Drive Solid State Drive	Identify the SATA port is connected to Solid State Drive or Hard Disk Drive
SATA Topology	Unknown ISATA Direct Connect Flex M2	Identify the Secondary SATA Topology if it is Default or ISATA or Flex or DirectConnect or M2

5.4.10 Sub-Menu: SATA Mode options

Aptio Setup Utility – Copyright © 2018 American Megatrends, Inc.

Platform
Configuration

SATA HDD Unlock	[Enable]	CPU Configuration parameters
SATA Led locate	[Rnable]	
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright © 2018 American Megatrends, Inc.

BIOS Item	Options	Description
SATA HDD Unlock	Disable Enable	Enable: HDD password unlock is enabled in the OS
SATA Led locate	Disable Enable	If enabled LED/SGPIO hardware is attached

5.5 Server Mgmt Menu

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.			
Main	Advanced	Platform Configuration	Server Mgmt
BMC Self Test Status		PASSED	CPU Configuration parameters
BMC Device Revision		32	
BMC Device Revision		1	
BMC Firmware Revision		1.06	
IPMI Version		2.0	
BMC Interface(s)		KCS, USB	
POST Watchdog Timer		[Disabled]	
POST Watchdog timeout		[6 minutes]	
POST Watchdog Timer Policy		[Reset]	
OS Watchdog Timer		[Disabled]	
OS Wtd Timer Timeout		[10 minutes]	
OS Wtd Timer Policy		[Reset]	
> BMC network configuration			><: Select Screen
> BMC User Setting			^v: Select Item
			Enter: Select
			+/-: Change Opt.
			F1: General Help
			F8: Previous Values
			F9: Optimized Default
			F10: Save & Exit
			ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
BMC Self Test Status	Info-only	Shows BMC Self Test Status
BMC Device ID	Info-only	Shows BMC Device ID
BMC Device Revision	Info-only	Shows BMC Device Revision
BMC Firmware Revision	Info-only	Shows BMC Firmware Revision
IPMI Version	Info-only	Shows IPMI Version
BMC Interface(s)	Info-only	Shows BMC Interface(s)
POST Watchdog Timer	Disable Enable	Enable or Disable POST Watchdog Timer(FRB-2 timer)
POST Watchdog timeout	3 minutes 4 minutes 5 minutes 6 minutes	Enter value Between 3 to 6 min for FRB-2 Timer Expiration value
POST Watchdog Timer Policy	Do Nothing Reset	Configure how the system should respond if the POST Watchdog Timer(FRB-2 Timer) expires. Not available if (FRB-2 Timer) is disabled.
OS Watchdog Timer	Disable Enable	If enabled, starts a BIOS timer which can only be shut off by Management Software

BIOS Item	Options	Description
		after the OS loads. Helps determine that the OS successfully loaded or follows the OS Boot Watchdog Timer policy.
OS Wtd Timer Timeout	5 minutes 10 minutes 15 minutes 20 minutes	Configure the length of the OS Boot Watchdog Timer. Not available if OS Boot Watchdog Timer is disabled."
OS Wtd Timer Policy	Do Nothing Reset	Configure how the system should respond if the OS Boot Watchdog Timer expires. Not available if OS Boot Watchdog Timer is disabled
BMC network configuration	Sub-Menu	Configure BMC network parameters
BMC User Setting	Sub-Menu	Press <Enter> to Add, Delete and Set Privilege level for users

5.5.1 Sub-Menu: BMC network Configuration

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Server

Mgmt

-- BMC network configuration--		
Configure IPV4 support		
LAN channel 1		
Configuration Address source	[Unspecified]	
Current Configuration Address source	DynamicAddressBmcDhcp	
Station IP address	0.0.0.0	
Subnet mask	0.0.0.0	
Station MAC address	00-30-64-10-09-50	
Router IP address	0.0.0.0	
Router MAC address	00-00-00-00-00-00	

Configure IPV6 support		

Lan channel 1		
IPV6 Support	[Enabled]	
Configuration Address source	[Unspecified]	
Current Configuration Address source	DynamicAddressBmcDhcp	
Station IP6 address	::	
Prefix Length	0	
IPV6 Router1 IP Address	::	
IPV6 address status	Active	
IPV6 DHCP Algorithm	DHCPv6	
		><: Select Screen
		^v: Select Item
		Enter: Select
		+/-: Change Opt.
		F1: General Help
		F8: Previous Values
		F9: Optimized Default
		F10: Save & Exit
		ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Configuration Address source	Unspecified Static DynamicBmcDhcp DynamicBmcNonDhcp	Select to configure LAN channel parameters statically or dynamically(by BIOS or BMC). Unspecified option will not modify any BMC network parameters during BIOS phase
IPV6 Support	Disable Enable	Enable or Disable LAN1 IPV6 Support

5.5.2 Sub-Menu: BMC User Setting

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Main	Advanced	Platform Configuration	Server Mgmt	Security	Boot	Save & Exit
------	----------	---------------------------	------------------------	----------	------	-------------

>Add User

>Delete user

>Change User Setting

><: Select Screen

^v: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F8: Previous Values

F9: Optimized Default

F10: Save & Exit

ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Add User	Sub-Menu	Press <Enter> to Add a User
Delete user	Sub-Menu	Press <Enter> to Delete a User
Change User Setting	Sub-Menu	Press <Enter> to Change User Settings

5.5.3 Sub-Menu: Add User

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

**Server
Mgmt**

BMC Add User Dtails	
User Name	
USER Password	
User Access	[Disable]
Channel No	0
User Privilege Limit	[Reserved]

><: Select Screen
 ^v: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F8: Previous Values
 F9: Optimized Default
 F10: Save & Exit
 ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
User Name	Enter to set user name	Enter BMC User Name
User Password	Enter to set password	Enter BMC User Password
User Access	Disable Enable	Enable/Disable the BMC User's Access
Channel No	0~15	Enter BMC Channel Number
User Privilege Limit	Reserved Callback User Operator Administrator OEM Proprietary No Access	Enter BMC User Privilege Limit for Selected Channel

5.5.4 Sub-Menu: Delete User

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

**Server
Mgmt**

BMC Delete User Dtails

User Name

USER Password

><: Select Screen
^v: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F8: Previous Values
F9: Optimized Default
F10: Save & Exit
ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
User Name	Enter to set user name	Enter BMC User Name
User Password	Enter to set password	Enter BMC User Password

5.5.5 Sub-Menu: Change User Setting

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Server
Mgmt

BMC Change User Setting	
User Name	
USER Password	
User Access	[Disable]
Channel No	0
User Privilege Limit	[Reserved]

><: Select Screen
 ^v: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F8: Previous Values
 F9: Optimized Default
 F10: Save & Exit
 ESC: Exit

Version 2.19.1268. Copyright © 2017 American Megatrends, Inc.

BIOS Item	Options	Description
User Name	Enter to set user name	Enter BMC User Name
User Password	Enter to set password	Enter BMC User Password
User Access	Disable Enable	Enable/Disable the BMC User's Access
Channel No	0~15	Enter BMC Channel Number
User Privilege Limit	Reserved Callback User Operator Administrator OEM Proprietary No Access	Enter BMC User Privilege Limit for Selected Channel

5.6 Security Menu

This menu contains the settings for system security.

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Main	Advanced	Platform	Server Mgmt	Security	Boot	Save & Exit
------	----------	----------	-------------	-----------------	------	-------------

Configuration

Password Description

If ONLY the Administrator's password is set, then this only limits access to Setup and is Only asked for when entering Setup.

If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the user will have Administrator rights.

The password length must be in the following range:

Minimum length	3
Maximum length	20

Administrator Password

User Password

> Secure Boot

HDD Security Configuration

><: Select Screen

^v: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F8: Previous Values

F9: Optimized Default

F10: Save & Exit

ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Administrator Password	Enter to set password	Configure/Clear Administrator Password. When pressing enter, a menu will be popped up for creating new password. When password installed, press enter without inputting password, it will clear password.
User Password	Enter to set password	Configure/Clear User Password. When pressing enter, a menu will be popped up for creating new password. When password installed, press enter without inputting password, it will clear password.
Secure Boot	Sub-Menu	For secure boot configuration.
HDD Security Configuration	Sub-Menu	For HDD security, it will list all HDD detected on motherboard. Select the HDD and then press enter can figure/clear HDD password.

When selecting a HDD to configure passwords, BIOS will enter another setup page as below. The method of configuring HDD password is the same as that for BIOS passwords. Once a password is set, it will reflect the status on the screen, such as 'HDD User Pwd Status' changed to 'INSTALLED'. When there is no HDD user password installed, you can change the master password without confirming the latest installed password. Once the HDD user password is installed, the HDD master password cannot be changed.

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Security

HDD Password Description		
Allows Access to Set, Modify and Clear HardDisk User and Master Passwords. User Password need to be installed for Enabling Security. Master Password can be Modified only when successfully unlocked with Master Password in POST		
HDD PASSWORD CONFIGURATION		
P4:ST9160412AS		
Security Supported	Yes	
Security Enabled	Yes	
Security Locked	No	
Security Frozen	No	
HDD User Pwd Status	INSTALLED	
HDD Master Pwd Status	INSTALLED	
Set User Password		
Set Master Password		
		><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

5.6.1 Sub-Menu: Secure Boot

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Security		
Secure Boot		
System Mode	User	Secure Boot activated when Platform Key(PK) is enrolled, System mode is User/Deployed, and CSM function is disabled
Secure Boot	Not Active	
Secure Boot Control	[Disabled]	><: Select Screen ^v: Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Default F10: Save & Exit ESC: Exit
> Key Management		

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Secure Boot	Info-only	
System Mode	Info-only	Showing current system mode.
Secure Boot	Info-only	Showing current state of secure boot function.
Secure Boot Control	Disabled Enabled	Secure Boot can be enabled if: 1. System running in User mode with enrolled Platform Key (PK) 2. CSM function is disabled.
Key Management	Sub-Menu	For installing/appending/erasing secure boot databases and keys.

5.6.2 Sub-Menu: Key Management

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Security

Key Management

Secure Boot variable	Size	Key#	Key Source
> Platform Key(PK)	0	0	No Key
> Key Exchange Keys	0	0	No Key
> Authorized Signatures	0	0	No Key
> Forbidden Signatures	0	0	No Key

Enroll Factory Defaults or load certificates from a file:

- 1.Public Key Certificate in:
 - a)EFI_SIGNATURE_LIST
 - b)EFI_CERT_X509 (DER encoded)
 - c)EFI_CERT_RSA2048(bin)
 - d)EFI_CERT_SHA256, 384, 512
- 2.Authenticated UEFI Variable
- 3.EFI PE/COFF Image

><: Select Screen
 ^v: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F8: Previous Values
 F9: Optimized Default
 F10: Save & Exit
 ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Platform Key(PK)	Enter	For installing/saving/erasing PK.
Key Exchange Keys	Enter	For installing/saving/appending/erasing KEK.
Authorized Signatures	Enter	For installing/saving/appending/erasing db.
Forbidden Signatures	Enter	For installing/saving/appending/erasing dbx.

5.7 Boot Menu

This menu contains the settings for bootable devices in the system.

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Main

Advanced

Platform Configuration

Server Mgmt

Security

Boot

Save & Exit

Boot Configuration

Quiet Boot

CSM Support

Network

Storage

Video

Boot mode select

Boot Configuration

Boot Option #1

Boot Option #2

Boot Option #3

Boot Option #4

Boot Option #5

Boot Option #6

Boot Option #7

Boot Option #8

Boot Option #9

> UEFI USB Key Drive BBS Priorities

> UEFI Application Boot Priorities

[Disable]

[Enabled]

[UEFI]

[UEFI]

[Legacy]

[UEFI]

[USB Hard Disk]

[USB CD/DVD]

[USB Key]

[USB Floppy]

[USB Lan]

[Network]

[Hard Disk]

[CD/DVD]

[UEFI AP:UEFI: Built...]

Select boot mode LEGACY /UEF

><: Select Screen

^v: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F8: Previous Values

F9: Optimized Default

F10: Save & Exit

ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Quiet Boot	Disabled Enabled	Enables or Disables Quiet Boot option.
CSM Support	Disabled Enabled	Enable to support operating system that only support legacy mode.
Network	Do not launch UEFI Legacy	Select the method of launch option ROM of network controller. UEFI will execute EFI driver and legacy will search option ROM of device to hook.
Storage	Do not launch UEFI Legacy	Select the method of launch option ROM of storage controller. UEFI will execute EFI driver and legacy will search option ROM of device to hook.

BIOS Item	Options	Description
Video	Do not launch UEFI Legacy	Select the method of launch option ROM of graphic controller. UEFI will execute EFI driver and legacy will search option ROM of device to hook.
Boot mode select	LEGACY UEFI	Select boot mode, LEGACY/UEFI.
Boot Option #1 ~ #9	#1: USB Hard Disk #2: USB CD/DVD #3: USB Key #4: USB Floppy #5: USB Lan #6: Network #7: Hard Disk #8: CD/DVD #9: Built-in EFI Shell	For boot priority setting.
XXXX Drive BBS Priorities	Sub-Menu	When the bootable device is attached to system and found by BIOS, it will be listed at boot option #. If there are many devices with the same device type found, it can set priority among these devices through this sub-menu.

5.8 Save & Exit Menu

Aptio Setup Utility – Copyright (C) 2017 American Megatrends, Inc.

Main	Advanced	Platform Configuration	Server Mgmt	Security	Boot	Save & Exit
------	----------	---------------------------	-------------	----------	------	------------------------

Save Changes and Exit

Discard Changes and Exit

Save Changes and Reset

Discard Changes and Reset

Save Options

Save Changes

Discard Changes

Restore Defaults

Save as User Defaults

Restore User Defaults

Boot Override

Launch EFI Shell from filesystem device

Exit system setup after saving the changes.

><: Select Screen

^v: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F8: Previous Values

F9: Optimized Default

F10: Save & Exit

ESC: Exit

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc.

BIOS Item	Options	Description
Save Changes and Exit	Enter	Save changed settings and exit BIOS setup utility.
Discard Changes and Exit	Enter	Skip changed setting and exit BIOS setup utility.
Save Changes and Reset	Enter	Save all changed settings and let system do reset to boot system.
Discard Changes and Reset	Enter	Discard all changed settings and let system do reset to boot system.
Save Changes	Enter	Save all changed settings.
Discard Changes	Enter	Discard changes done so far to any of the setup options.
Restore Default	Enter	Load the default made when BIOS was built.
Save as User Default	Enter	Save all changed done so far as User Defaults.
Restore User Default	Enter	Load the default that user save as user defaults.
Boot Override	Info-only	


Important Safety Instructions

For user safety, please read and follow all **instructions**, **WARNINGS**, **CAUTIONS**, and **NOTES** marked in this manual and on the associated equipment before handling/operating the equipment.

1. Read these safety instructions carefully.
2. Keep this user's manual for future reference.
3. Read the specifications section of this manual for detailed information on the operating environment of this equipment.
4. The equipment can be operated at an ambient temperature of 40°C.
5. When installing/mounting or uninstalling/removing equipment; or when removal of the chassis lid required for user servicing (Section 3.1-3.5):
 - Turn off power and unplug any power cords/cables, and
 - Reinstall the chassis lid before restoring power.



Hazardous moving parts. Keep body parts out of the motion path.



6. To avoid electrical shock and/or damage to equipment:
 - Keep equipment away from water or liquid sources;
 - Keep equipment away from high heat or high humidity;
 - Keep equipment properly ventilated (do not block or cover ventilation openings);
 - Make sure to use recommended voltage and power source settings;
 - Always install and operate equipment near an easily accessible electrical socket-outlet;
 - Secure the power cord (do not place any object on/over the power cord);
 - Only install/attach and operate equipment on stable surfaces and/or recommended mountings;
 - If the equipment will not be used for long periods of time, turn off and unplug the equipment from its power source.
 - The power cord must be connected to a socket or outlet with a ground connection.
7. Never attempt to fix the equipment. Equipment should only be serviced by qualified personnel.
8. An RTC battery may be provided for uninterrupted, backup or emergency power.



Risk of explosion if battery is replaced with one of an incorrect type. Please dispose of used batteries appropriately.

9. This equipment is not suitable for use in locations where children are likely to be present.
10. Equipment must be serviced by authorized technicians when:
 - The power cord or plug is damaged;
 - Liquid has penetrated the equipment;
 - It has been exposed to high humidity/moisture;
 - It is not functioning or does not function according to the user's manual;
 - It has been dropped and/or damaged; and/or,
 - It has an obvious sign of breakage.
11. Please pay strict attention to all warnings and advisories appearing on the device, to avoid injury or damage.
12. The equipment may have more than one power supply input. To reduce the risk of electrical shock, trained personnel should disconnect all power supply inputs before servicing.



Shock hazard! Disconnect all power supply inputs before servicing.



Shock hazard!
Risque d'électrocution!



Multiple power sources
Sources d'alimentation multiples

13. It is recommended that equipment be installed only in a server room or computer room where access is:
 - Restricted to qualified service personnel or users familiar with restrictions applied to the location, reasons therefor, and any precautions required;
 - Only afforded by the use of a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location.
14. Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.


Consignes de Sécurité Importantes

Pour assurer la sécurité de l'utilisateur, veuillez lire et suivre toutes les **directives**, ainsi que les **AVERTISSEMENTS**, **MISES EN GARDE** et **REMARQUES** de ce manuel et indiqués sur l'équipement associé avant de manipuler ou utiliser l'équipement.

1. Veuillez lire attentivement ces instructions de sécurité avec soin.
2. Veuillez conserver ce manuel pour référence future.
3. Veuillez lire la section des spécifications de ce manuel pour avoir des informations détaillées sur l'environnement d'exploitation de cet équipement.
4. L'équipement peut être utilisé à une température ambiante de 40 °C.
5. Lors de l'installation ou du montage et de la désinstallation ou de la dépose de l'équipement; ou lors de la dépose du couvercle du châssis pour procéder à l'entretien par l'utilisateur (Sections 3.1-3.5):
 - Coupez l'alimentation et débranchez les cordons et les câbles d'alimentation, et
 - Reposez le couvercle du châssis avant de remettre l'alimentation.



Pièces mobiles dangereuses. Gardez les parties du corps hors de la trajectoire.



6. Pour éviter un risque d'électrocution et pour éviter d'endommager l'équipement :
 - Éloignez l'équipement de l'eau et de toute source liquide;
 - Éloignez l'équipement de toute source de chaleur ou d'humidité élevée;
 - Gardez l'équipement correctement ventilé (ne pas bloquer ou couvrir les ouvertures de ventilation);
 - Veillez à utiliser la tension recommandée et les réglages adéquats pour la source d'alimentation;
 - Veuillez toujours installer et exploiter l'équipement à proximité d'une prise de courant facilement accessible;
 - Assurez-vous que le cordon d'alimentation est acheminé de manière sécuritaire (ne déposez aucun objet dessus);
 - Installez, fixez et utilisez l'équipement sur des surfaces stables ou sur les fixations recommandées uniquement;
 - Si l'équipement n'est pas utilisé pendant une longue période, éteignez-le et débranchez-le de sa source d'alimentation.
 - Le cordon d'alimentation doit être connecté à une prise ou à une prise de courant avec mise à la terre.
7. N'essayez jamais de réparer l'équipement. L'équipement ne doit être réparé que par du personnel qualifié.

8. Une pile au lithium peut être installée pour assurer l'alimentation de secours ou d'urgence en continu.



mise en garde

Risque d'explosion si la batterie est remplacée par une batterie d'un type incorrect. Veuillez éliminer les piles usagées de manière appropriée.

9. Cet équipement ne convient pas à une utilisation dans des lieux pouvant accueillir des enfants.
10. L'équipement doit être entretenu par des techniciens agréés lorsque :
- le cordon d'alimentation est endommagé ou lorsque la fiche électrique est endommagée;
 - du liquide a pénétré à l'intérieur de l'équipement;
 - l'équipement a été exposé à un taux d'humidité élevé;
 - l'équipement ne fonctionne pas ou ne fonctionne pas conformément au manuel de l'utilisateur;
 - l'équipement est tombé ou lorsqu'il a été endommagé;
 - l'équipement présente un signe évident de défaillance.
11. Veuillez porter une attention rigoureuse à tous les avertissements et à tous les avis figurant sur l'appareil, pour éviter des blessures ou des dommages.
12. L'équipement peut avoir plus d'une entrée d'alimentation. Pour réduire le risque d'électrocution, le personnel qualifié devrait déconnecter toutes les entrées d'alimentation avant de procéder à l'entretien.



mise en garde

Risque d'électrocution! Débranchez toutes les entrées d'alimentation avant de procéder à l'entretien.



Shock hazard!

Risque d'électrocution!



Multiple power sources

Sources d'alimentation multiples

13. Il est recommandé que l'équipement soit installé que dans une salle de serveur ou de la salle informatique où:
- L'accès est limité au personnel de maintenance qualifié ou utilisateurs familiers avec les restrictions appliquées à l'emplacement, motifs, et tout les précautions nécessaires, et;
 - L'accès est uniquement assurée par l'utilisation d'un outil ou clé, ou d'autres moyens de sécurité, et est contrôlé par l'autorité responsable de l'emplacement.
14. Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.

Getting Service

Ask an Expert: <http://askanexpert.adlinktech.com>

ADLINK Technology, Inc.

Address: 9F, No.166 Jian Yi Road, Zhonghe District
New Taipei City 235, Taiwan
新北市中和區建一路 166 號 9 樓
Tel: +886-2-8226-5877
Fax: +886-2-8226-5717
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.

Address: 5215 Hellyer Avenue, #110, San Jose, CA 95138, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-360-0222
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.

Address: 上海市浦东新区张江高科技园区芳春路 300 号 (201203)
300 Fang Chun Rd., Zhangjiang Hi-Tech Park, Pudong New Area
Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology GmbH

Address: Hans-Thoma-Strasse 11, D-68163, Mannheim, Germany
Tel: +49-621-43214-0
Fax: +49-621 43214-30
Email: emea@adlinktech.com

Please visit the Contact page at www.adlinktech.com for information on how to contact the ADLINK regional office nearest you.