

RK-606UC Chassis Manual

INDEX

INDEX	P1
PACKING CONTAIN	P2
INSTALLATION GUIDE	P3-P6

PACKING CONTAIN

Chassis Front View



Chassis Rear View



Packing Bag 1



Packing Bag 2



Rubber Foot* 4



機箱側邊固定架

待補照片

INSTALLATION GUIDE


Remove Screws




Open Chassis up cover




Fixed Backplane with Screws



**Fixed Power with
Holder Bracket**



**Plug ATX 20 Pin
connector into
Socket**



Take User's SBC




**Plug in
HD LED
Power LED
Rocker SW
on SBC**



Speaker Reset HDD S/W
P/W LED ATX PWR ON



**Plug in Front
Access USB on
SBC**




Remove Drive Bay



**Fixed HD / FDD
CD-Rom on Drive
with Screws**



Add HD Cable



**Screw back onto
Chassis**

