

cPCI-3E10 Series

User's Manual

3U CompactPCI® 4/2 Port
Gigabit Ethernet Card



Manual Rev.:	2.1 Rev.
Revision Date:	January 6, 2026
Part Number:	50M-15073-1010

Revision History

Revision	Description	Date	By
2.0	Initial release	2011-11-15	JC
2.1	Introduction, specification, board and mechanical layout, driver installation updated	2026-01-06	AL

Preface

Copyright


Copyright 2026 ADLINK Technology, Inc. This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Disclaimer



The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer. In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Environmental Responsibility

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.



Battery Labels (for products with battery)



California Proposition 65 Warning



WARNING: This product can expose you to chemicals including acrylamide, arsenic, benzene, cadmium, Tris(1,3-dichloro-2-propyl)phosphate (TDCPP), 1,4-Dioxane, formaldehyde, lead, DEHP, styrene, DINP, BBP, PVC, and vinyl materials, which are known to the State of California to cause cancer, and acrylamide, benzene, cadmium, lead, mercury, phthalates, toluene, DEHP, DIDP, DnHP, DBP, BBP, PVC, and vinyl materials, which are known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Conventions

Take note of the following conventions used throughout this manual to make sure that users perform certain tasks and instructions properly.



NOTE:

Additional information, aids, and tips that help users perform tasks.



CAUTION:

Information to prevent **minor** physical injury, component damage, data loss, and/or program corruption when trying to complete a task.



WARNING:

Information to prevent **serious** physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.

Table of Contents

Preface	iii
List of Figures	vi
1 Introduction	7
1.1 Overview	7
1.2 Features	7
2 Specifications	9
2.1 Product Specifications	9
2.2 I/O Connectivity Table	9
3 Block Diagram	11
4 Board Layout	13
4.1 cPCI-3E10 Series Board Layout	13
4.2 cPCI-3E12 Board Layout	14
4.3 cPCI-R3E10 RTM Board Layout	14
5 Connector Pinouts and Jumper Settings	17
5.1 RJ-45 Ethernet Connectors	17
5.2 LAN Routing Jumper (JP1)	17
5.3 CompactPCI J1 Connector	18
5.4 CompactPCI J2 Connector	18
6 Driver Installation	21
Safety Instructions	22
Getting Services	23

List of Figures

Figure 1: cPCI-3E10 functional block diagram.....	11
Figure 2: cPCI-3E12 functional block diagram.....	11
Figure 3: cPCI-3E10 board layout	13
Figure 4: cPCI-3E10 front panel	13
Figure 5: cPCI-3E12 board layout	14
Figure 6: cPCI-3E10 RTM board layout.....	14
Figure 7: cPCI-3E10 RTM front panel	15

1 Introduction

1.1 Overview

The cPCI-3E10 Series is 3U CompactPCI Gigabit Ethernet peripheral card equipped with Intel® i210IT PCIe Gigabit Ethernet controllers. The cPCI-3E10 provides four GbE ports on the front panel (RJ-45) with two switchable to the rear transition module, the cPCI-3E12 provides two GbE ports on the front panel (RJ-45), and the cPCI-3E10-SUB provides two Fast Ethernet ports on the front panel (DB-9).

An optional Rear Transition Module (cPCI-R3E10) is available to provide rear access to the GbE ports switched from the cPCI-3E10 front panel.

1.2 Features

- Standard 3U 4HP CompactPCI form factor
- Up to 64-bit/66MHz CompactPCI Interface
- Up to four Intel® i210IT Ethernet controllers with fully-integrated GbE MAC & PHY
- Four or two 10/100/1000BASE-T Gigabit Ethernet ports via RJ-45 connectors
- Two LAN ports switchable to rear (cPCI-3E10 only)
- Two Fast Ethernet ports via D-sub 9-pin connectors (cPCI-3E10-SUB only) for harsh environment applications
- PICMG® 2.0 R3.0 compliant



CAUTION:

This product must be protected from static discharge and physical shock. Never remove any of the components except at a static-free workstation. Use the anti-static bag shipped with the product when putting the board on a surface. Wear an anti-static wrist strap properly grounded on one of the system's ESD ground jacks when installing or servicing system components.

This page intentionally left blank.

2 Specifications

2.1 Product Specifications

2.1.1 cPCI-3E10 Specifications

PCI Bus Architecture	• Bus Type: PCI • Bus Width: 32- or 64-bit • Bus Speed: 33/66 MHz • PCI Voltage: 3.3V or 5V universal
Ethernet Controller	• Intel i210IT Gigabit Ethernet Controller running at PCIe 1.1 (2.5 GHz) x1 • 4x GbE ports on cPCI-3E10, 2x GbE ports on cPCI-3E12 • Data rates supported (per port): 10/100/1000 Mbps • IEEE Standard/Network Topology: 10BASE-T, 100BASE-TX, 1000BASE-T • IEEE 802.3ab compliant
Ethernet Ports	• cPCI-3E10/3E12: Four or two RJ-45 connectors • cPCI-3E10-SUB: Two DB-9 10/100 Mbps Fast LAN connectors • cPCI-R3E10: Two RJ-45 connectors • Wiring: Cat-5, 4-pair, Maximum 100 meters cable distance
Ethernet LEDs	• Each RJ-45 port and DB-9 port has two "Link/Active" LEDs
Boot ROM	• LAN Boot ROM: 128KB onboard
OS Support	• Windows 10 • Red Hat Enterprise Linux 5.0 and above (Contact ADLINK for other OS availability)
Network Management	• ACPI Power Management • Supports Intel Preboot Execution Environment (PXE 2.0) for remote boot
Environment	• Operating Temperature: 0°C to 60°C • Storage Temperature: -40°C to 70°C • Humidity: 95% @70°C, non-condensing
Dimensions	• 149 mm x 74 mm x 10 mm (L x W x H)



Specifications are subject to change without prior notice.

NOTE:

2.2 I/O Connectivity Table

Function	Model	Faceplate
GbE (RJ-45)	cPCI-3E10	Y x4
	cPCI-3E12	Y x2
	cPCI-R3E10	Y x2
Fast Ethernet (DB-9)	cPCI-3E10-SUB	Y x2

This page intentionally left blank.

3 Block Diagram

3.1.1 cPCI-3E10 Block Diagram

The cPCI-3E10 is based on four Intel® i210IT PCI express Giga-bit Ethernet controllers. The Intel® i210IT is a highly integrated chip including Ethernet MAC and PHY. Please refer to the Intel® i210IT datasheet for more information.




Figure 1: cPCI-3E10 functional block diagram

3.1.2 cPCI-3E12 Block Diagram





Figure 2: cPCI-3E12 functional block diagram

This page intentionally left blank.

4 Board Layout

4.1 cPCI-3E10 Series Board Layout



JP1	LAN routing jumper	U26	PCIe-to-PCI Bridge PI7C9X111
J1/2	CompactPCI connectors	U25	PCIe Switch PI7C9X2G808
LAN1/2	GbE ports (RJ-45 w/ transformer)	U10/12/14/16	Intel i210IT GbE controllers
LAN3/4	GbE ports (RJ-45)		

Figure 3: cPCI-3E10 board layout




Figure 4: cPCI-3E10 front panel

4.2 cPCI-3E12 Board Layout




Figure 5: cPCI-3E12 board layout

4.3 cPCI-R3E10 RTM Board Layout




Figure 6: cPCI-3E10 RTM board layout




Figure 7: cPCI-3E10 RTM front panel


This page intentionally left blank.

5 Connector Pinouts and Jumper Settings

5.1 RJ-45 Ethernet Connectors

On the cPCI-3E10, LAN1/2 correspond to "A/B", and LAN3/4 correspond to "C/D". On the cPCI-3E12, LAN1/2 correspond to "C/D". On the cPCI-R3E10 RTM, LAN1/2 correspond to "A/B".

Pin #	10BASE-T/ 100BASE-TX	1000BASE-T
1	TX+	TRANS_ A/B/C/D_MDIP0
2	TX-	TRANS_ A/B/C/D_MDIN0
3	RX+	TRANS_ A/B/C/D_MDIP1
4	—	TRANS_ A/B/C/D_MDIP2
5	—	TRANS_ A/B/C/D_MDIN2
6	RX-	TRANS_ A/B/C/D_MDIN1
7	—	TRANS_ A/B/C/D_MDIP3
8	—	TRANS_ A/B/C/D_MDIN3



LAN LED definitions

Status	Speed LED (Green/Orange)	Activity LED (Yellow)
Network link is not established or system powered off	OFF	OFF
10 Mbps	Link	OFF
	Active	ON
100 Mbps	Link	Green
	Active	Blinking
1000 Mbps	Link	Orange
	Active	Blinking

5.2 LAN Routing Jumper (JP1)

The cPCI-3E10 is equipped with a jumper JP1 to transfer LAN1/2 (i210IT-A and i210IT-A) to J2 (RTM). See "cPCI-3E10 Board Layout" on page 11 for the location of JP1.

Short pins 1 and 2 on JP1 to route LAN1/2 to the front RJ-45 connectors (default). To route LAN1/2 to J2, remove the shunt shorting pins 1 and 2 (it can be placed on either pin for storage).

5.3 CompactPCI J1 Connector

Pin	Z	A	B	C	D	E	F
25	GND	P5V	CPCI_REQ64-L	CPCI_ENUM-L	P3V3	P5V	GND
24	GND	CPCI_AD1	P5V	NC	CPCI_AD0	CPCI_ACK64-L	GND
23	GND	P3V3	CPCI_AD4	CPCI_AD3	P5V	CPCI_AD2	GND
22	GND	CPCI_AD7	GND	P3V3	CPCI_AD6	CPCI_AD5	GND
21	GND	P3V3	CPCI_AD9	CPCI_AD8	PCI_M66EN	CPCI_CBE-L0	GND
20	GND	CPCI_AD12	GND	NC	CPCI_AD11	CPCI_AD10	GND
19	GND	P3V3	CPCI_AD15	CPCI_AD14	GND	CPCI_AD13	GND
18	GND	CPCI_SERR-L	GND	P3V3	CPCI_PAR	CPCI_CBE-L1	GND
17	GND	P3V3	IPMB_CLK	IPMB_DAT	GND	CPCI_PERR-L	GND
16	GND	CPCI_DEVSEL-L	GND	NC	CPCI_STOP-L	CPCI_LOCK-L	GND
15	GND	P3V3	CPCI_FRAME-L	CPCI_IRDY-L	GND	CPCI_TRDY-L	GND
12-14	Key						
11	GND	CPCI_AD18	CPCI_AD17	CPCI_AD16	GND	CPCI_CBE-L2	GND
10	GND	CPCI_AD21	GND	P3V3	CPCI_AD20	CPCI_AD19	GND
9	GND	CPCI_CBE-L3	CPCI_IDSEL	CPCI_AD23	GND	CPCI_AD22	GND
8	GND	CPCI_AD26	GND	NC	CPCI_AD25	CPCI_AD24	GND
7	GND	CPCI_AD30	CPCI_AD29	CPCI_AD28	GND	CPCI_AD27	GND
6	GND	CPCI_REQ-L0	GND	P3V3	CPCI_CLK	CPCI_AD31	GND
5	GND	NC	NC	CPCI_RST-L	GND	CPCI_GNT-L0	GND
4	GND	NC	NC	NC	NC	NC	GND
3	GND	CPCI_INTA-L	CPCI_INTB-L	CPCI_INTC-L	P5V	CPCI_INTD-L	GND
2	GND	CPCI_TCK	P5V	CPCI_TMS	NC	CPCI_TDI	GND
1	GND	P5V	NC	CPCI_TRST-L	NC	P5V	GND

5.4 CompactPCI J2 Connector

Pin	Z	A	B	C	D	E	F
22	GND	N28342162	N28355309	N28355465	N28355622	N28346930	GND
21	GND	NC	GND	NC	NC	NC	GND
20	GND	NC	GND	NC	GND	NC	GND
19	GND	GND	GND	NC	NC	NC	GND
18	GND	NC	NC	NC	GND	NC	GND
17	GND	NC	GND	NC	NC	NC	GND
16	GND	NC	NC	NC	GND	NC	GND
15	GND	NC	GND	NC	NC	NC	GND
14	GND	NC	NC	NC	GND	NC	GND
13	GND	P1V8_LANB	GND	NC	NC	P1V8_LANA	GND
12	GND	LANB_LED_100-L	LANB_LED_1000-L	LANB_LED_ACT-L	GND	LANA_LED_ACT-L	GND
11	GND	NC	N28043456	NC	P3V3	P5V	GND
10	GND	NC	NC	NC	N28028706	NC	GND
9	GND	GND	GND	LANA_LED_100-L	LANA_LED_1000-L	NC	GND
8	GND	TRANS_J2_B_MDIP2	TRANS_J2_B_MDIN2	GND	GND	GND	GND
7	GND	GND	GND	GND	TRANS_J2_A_MDIP2	TRANS_J2_A_MDIN2	GND
6	GND	TRANS_J2_B_MDIP3	TRANS_J2_B_MDIN3	GND	GND	GND	GND
5	GND	GND	GND	GND	TRANS_J2_A	TRANS_J2_A	GND

					_MDIP3	_MDIN3	
4	GND	TRANS_J2_B _MDIP0	TRANS_J2_B _MDIN0	GND	GND	GND	GND
3	GND	GND	GND	GND	TRANS_J2_A _MDIP0	TRANS_J2_A _MDIN0	GND
2	GND	TRANS_J2_B _MDIP1	TRANS_J2_B _MDIN1	GND	GND	GND	GND
1	GND	GND	GND	GND	TRANS_J2_A _MDIP1	TRANS_J2_A _MDIN1	GND

This page intentionally left blank.

6 Driver Installation

Drivers can be downloaded through the following link.

https://www.adlinktech.com/products/CompactPCI/Peripherals_Accessories/cPCI-3E10_3E12

Safety Instructions

Read and follow all instructions marked on the product and in the documentation before you operate your system. Retain all safety and operating instructions for future use.

- Please read these safety instructions carefully.
- Please keep this User's Manual for later reference.
- Read the specifications section of this manual for detailed information on the operating environment of this equipment.
- When installing/mounting or uninstalling/removing equipment, turn off the power and unplug any power cords/cables.
- To avoid electrical shock and/or damage to equipment:
 - Keep equipment away from water or liquid sources.
 - Keep equipment away from high heat or high humidity.
 - Keep equipment properly ventilated (do not block or cover ventilation openings).
 - Make sure to use recommended voltage and power source settings.
 - Always install and operate equipment near an easily accessible electrical socket-outlet.
 - Secure the power cord (do not place any object on/over the power cord).
 - Only install/attach and operate equipment on stable surfaces and/or recommended mountings.
 - If the equipment will not be used for long periods of time, turn off and unplug the equipment from its power source.
- Never attempt to fix the equipment. Equipment should only be serviced by qualified personnel.

Getting Services

Ask an Expert: <https://www.adlinktech.com/en/Askanexpert>

ADLINK Technology, Inc.

Address: No. 66, Huaya 1st Road, Guishan District
Taoyuan City 333, Taiwan
Tel: +886-3-216-5088
Fax: +886-3-328-5723
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.

Address: 6450 Via Del Oro, San Jose, CA 95119-1208, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-600-1189
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.

Address: 300 Fang Chun Rd., Zhangjiang Hi-Tech Park, Pudong New Area
Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology GmbH

Address: Hans-Thoma-Strasse 8-10, 68163, Mannheim, Germany
Tel: +49-621-43214-0
Fax: +49-621 43214-30
Email: emea@adlinktech.com

Please visit the Contact page at www.adlinktech.com for information on how to contact the ADLINK regional office nearest you.